

Manufacturer	Model	iGo Power Tips	
Mobile Phone / PDAs		Order Code	
Alltel	UTStarcom PPC6700	A53	N28FX
Apple	iPhone	A61	N34FX
AT&T	2125, 8125, 8500, 8525, Tilt	A53	N28FX
Audiovox	PPC-6700, SMT5600	A53	N28FX
Belkin	Skype WiFi F1PP000GN-SK	A32	N20FX
Belkin	Skype WiFi F1PP000GN-SK	A32	N20FX
BlackBerry	5790, 5820, 6210, 6220, 6230, 6280, 6510, 7100g, 7100i, 7100r, 7100t, 7100v, 7100x, 7105t, 7130c, 7130e, 7130g, 7130v, 7210, 7230, 7250, 7280, 7290, 7510, 7520, 8100g, 8700c, 8700f, 8700g, 8700r, 8700v, 8703e, 8707g, 8707v, 8800, 8800g, 8820, 8830, Curve 8300, Pearl 8100, Curve 8310, Curve 8310 (red), Curve 8320, Pearl 8100 (black), Pearl 8100 (blue), Pearl 8100 (pale gold), Pearl 8100 (sunset), Pearl 8120, Pearl 8120 (blue), Pearl 8120 (titanium), Pearl 8130 (amethyst), Pearl 8130 (silver), Red Pearl 8100, White Pearl 8100	A29	NI8FX
CHT	CHT 9000	A53	N28FX
Cingular	2125, 8125, 8500, 8525	A53	N28FX
Dopod	565, 575, 577w, 585, 818, 818 Pro, 828, 838, 838 Pro, 900, C720W, C800, D810, M700, P800W, U1000	A53	N28FX
Grundig	GR890	A53	N28FX
Helio	Ocean	A40	N23FX
HP	hw6510, hw6940, hx2190, hx2790, hx2795, iPAQ h1700, iPAQ h1910, iPAQ h1915, iPAQ h1920, iPAQ h1930, iPAQ h1935, iPAQ h1937, iPAQ h1940, iPAQ h1945, iPAQ h2210, iPAQ h2215, iPAQ h3830, iPAQ h3835, iPAQ h3850, iPAQ h3860, iPAQ h3870, iPAQ h3875, iPAQ h3950, iPAQ h3955, iPAQ h3970, iPAQ h3975, iPAQ h4150, iPAQ h4155, iPAQ h4350, iPAQ h4355, iPAQ h5450, iPAQ h5455, iPAQ h5550, iPAQ h5555, iPAQ h6315, iPAQ H6340, iPAQ h6365, iPAQ hw6515, iPAQ hw6910, iPAQ hw6915, iPAQ hw6920, iPAQ hw6925, iPAQ hw6945, iPAQ hw6950, iPAQ hw6955, iPAQ hx2110, iPAQ hx2115, iPAQ hx2410, iPAQ hx2415, iPAQ hx2490, iPAQ hx2495, iPAQ hx2750, iPAQ hx2755, iPAQ hx4700, iPAQ hx4705, iPAQ rx1950, iPAQ rx1955, iPAQ rx3115, iPAQ rx3400, iPAQ rx3715, iPAQ rz1710, iPAQ rz1715,	A20	NI7FX
HTC	5800, P3350, P4350, S621, S710, S720, Advantage X7501, Apache, Artemis P3300, Athena, Excalibur s620, Herald, Hermes 100, Hermes 200, Hermes 300, Kaiser, Libra, Love, Mogul, MTeoR, Prophet PM300, Tilt 8925, Titan, Touch, Trinity P3600, TyTN, TyTN II, Vox	A53	N28FX
i mate	K-Jam, SP3, SP3i, SP5, SP5m, Jam, Jamin, JASJAM, JASJAR	A53	N28FX
Krome	Navigator FI, Spy	A53	N28FX
LG	1400, 1400C, 4020, A7110, B2000, B2050, B2100, C1100, C1200, C1300, C1500, C2000, C2200, C3300, C3310, C3320, CE500, CG225, CG300, CU320, CU400, CU405, CU500, F1200, F2100, F2250, F2300, F2400, F7200, F7250T, F9100, F9200, G233, G262, G4010, G4011, G4015, G4050, G7050, HD5330, KG220, KG225, KG920, L1100, I1150, I1400, L342i, L343i, L5100, M4400, M4410, M6100, P7200, S5000, S5200, T5100, TD6100, TU500, U300, U400, U8110, U8120, U8130, U8138, U8150, U8180, U8290, U8330, U8360, U8380, U880, U890	A40	N23FX
	AX275, CE110, CG180, CU515, CU575, EnV9900, KG320, KG810, LX150, LX160, VX8350, VX8550, VX8550 Black, VX8550 Dark Blue, VX8550 Dark Red, VX8550 Metallic Black, VX8600, VX8700, VX9400, VX9900, Cherry Chocolate, Chocolate KG800, Chocolate VX8500, Chocolate Flip 8600, Chocolate-Green, Chocolate-Pink, Chocolate-Red, ENV-ORANGE, ENV-GREEN, Mint Chocolate, MUZIQ LX570, MUZIQ-PINK, PRADA KE850, Shine KE970, Shine U970, The Wave AX380, TRAX, VENUS VX8800, VOYAGER VX10K, White Chocolate	A92	N38FX
MDA	Compact	A53	N28FX
Motorola	A1200, A668, A70, A732, A780, A910, C305, C362, C363, E1070, E610, E615, E680, E680i, E685, ic402, ic502, L2, M300, PEBL, V190, V191, V195, V197, V235, V320, V323, V323i, V325, V325i, V360, V361, V365, V660, W315, W375, W385, W490, W510, KRZR K1, KRZR K1m, KRZR K3, KRZR maxx K3, Ming A1200, MOTOFOE F3, MotorolaQ, RAZR MAXX FERRARI V6, RAZR MAXX V6, RAZR maxx Ve, RAZR V3, RAZR V3 (RED), RAZR V3 BLK, RAZR V3a, RAZR V3c, RAZR V3i, RAZR V3i DG, RAZR V3im, RAZR V3m, RAZR V3r, RAZR V3t, RAZR V3x, RAZR V3xx, red RAZR V3i, red RAZR V3m, RIZR Z3, RIZR Z6tv, ROKR E2, ROKR E6, ROKR Z6, SLVR i-mode, SLVR L6, SLVR L7, SLVR L7c, SLVR (RED), SVLR L7i	A32	N20FX
	E8, Razr2; V8, V9, V9M, Z6, Z8, Z10, MotoQ, U9	A97	N34GA
NEC	e228, e313, e606, e616, e616v, e808N, e808S, e808Y	A45	N25FX
Nokia	1108, 1221, 1260, 1261, 2115i, 2260, 2270, 2275, 2280, 2285, 252, 282, 3210, 3285, 3300, 3310, 3315, 3330, 3350, 3360, 3361, 3390, 3395, 3410, 3510, 3510i, 3520, 3530, 3560, 3570, 3585, 3585i, 3586, 3586i, 3587i, 3588i, 3589i, 3590, 3595, 3600, 3610, 3620, 5120, 5125, 5140, 5160, 5165, 5170i, 5180i, 5185i, 5190, 5210, 5510, 6010, 6015i, 6016i, 6120, 6160, 6161, 6162, 6185i, 6190, 6200, 6210, 6250, 6255i, 6310, 6310i, 6340, 6340i, 6360, 6370, 6385, 640, 650, 6510, 6560, 6585, 6590, 6590i, 6620, 6650, 6651, 6800, 6810, 6820, 6822, 7110, 7160, 7190, 7210, 7650, 8210, 8250, 8260, 8265, 8265i, 8270, 8280, 8290, 8310, 8390, 8810, 8850, 8850 Gold, 8855, 8860, 8890, 8910, 8910i, 9200, 9210i, 9290, 9300, THR850, THR880, 1100, 1101, 1110, 1110i, 1112, 1600, 2100, 2112, 2116, 2116i, 2118, 2125, 2125i, 2126i, 2128i, 2255, 2300, 2600, 2610, 2626, 2650, 2651, 2652, 3100, 3105, 3108, 3120, 3125, 3200, 3205, 3220, 3230, 3650, 3660, 5100, 5140i, 5165i, 5300 (classic), 6015, 6019i, 6020, 6021, 6030, 6060, 6061, 6062, 6100, 6101 (Classic), 6108, 6170, 6220, 6225, 6230, 6230i, 6235, 6235i, 6236i, 6255, 6256i, 6260, 6600, 6610, 6610i, 6630, 6670, 6680, 6681, 6682, 7200, 7250, 7250i, 7260, 7270, 7280, 7380, 7610, 7700, 7710, 8800, 8801, 9300i, 9500, E60, E70, N-Gage, N-GageQD, Shorty	A95	N39FX

Manufacturer	Model	iGo Connectors	
Mobile Phone / PDAs		Order Code	
Nokia	New Micro USB - 8800 Luna, 7900 Prism, 7500	A97	N34GA
	1200, 1208, 1650, 2135, 2310, 2630, 2760, 2865i, 3109 Classic, 3110 Classic, 3152, 3155, 3155i, 3250, 3250 Xpress Music, 3500 Classic, 5070, 5200, 5300 XpressMusic, 5310 XpressMusic, 5500 Sport, 5610 XpressMusic, 6070, 6080, 6085, 6086, 6101, 6102, 6102i, 6103, 6111, 6120 Classic, 6121 Classic, 6125, 6126, 6131, 6131 NFC, 6133, 6136, 6151, 6152, 6155, 6155i, 6165i, 6233, 6233 Music Edition, 6265, 6265i, 6267, 6268, 6270, 6275i, 6280, 6282, 6288, 6290, 6300, 6500 Slide, 6555, 7360, 7370, 7372, 7373, 7390, 7500 Prism, 770 Internet Tablet, 8800 Sirocco Edition, 8800 Sirocco Gold Edition, E50, E61, E61i, E62, E65, E90 Communicator, N70, N70 Music Edition, N71, N72, N73, N73 Music Edition, N75, N76, N77, N80, N800 Internet Tablet, N80ie, N90, N91, N91 8GB, N91 WCDMA, N92, N93, N93i, N95	A105	N40FX
NTT DoCoMo	hTc Z	A53	N28FX
O2	Atom, XDA Exec, XDA IQ, XDA Mini Pro, XDA Mini S, Xda Neo, Xda Orion, XDA Cosmo, XDA Orbit, XDA SP, XDA Trion, Xphone II, Xphone IIm	A53	N28FX
Orange	M650, M700, SPV C550, SPV C600, SPV E650, SPV M3000, SPV M3100, SPV M3130, SPV M5000, SPV M600, SPV M700	A53	N28FX
Palm	TX, Centro, LifeDrive, Treo 650, Treo 680, Treo 700p, Treo 700w, Treo 700wx, Treo 750, Treo 750v, Treo 755p, Tungsten E2, Tungsten T5	A43	N24FX
	Z22	A53	N28FX
Panasonic	EB-MX6, EB-MX7, EB-SA6, EB-SA7, EB-VS2, EB-VS3, EB-VS6, EB-VS7	A45	N25FX
Pantech	PN-215	A40	N23FX
Qtek	4040, 8010, 8020, 8100, 8300, 8310, 9000, 9100, 9600, S100, S110, S200	A53	N28FX
Sagem	910, 912, 916, 919, 920, 922, 926, 929, 930, 930L, 932, 932L, 936, 936L, 939, 939L, 940, 942, 946, 949, 950, 952, 956, 959, MC300X, MW302x, MW304X, MW930, MW932, MW936, MW939, MW940, MW942, MW946, MW949, MW950, MW9500, MW952, MW956, MW959, MW9X2, MW9X9, MY302X, MY303X, MY304X, MY305X, MY306X, myV-55, myV-56, myV-65, myV-75, myV-76, myX-1, myX-2, myX-3, myX-4, myX-5, myX-6, myX-7, myX-8, myX1-2, myX2-2, myX3-2, myX5-2, myX6-2, myxG-5, myZ-3, PW302X, PW304X, SG322i, VSI	A56	N31FX
Samsung	SCH-A210, SCH-A310, SCH-A399, SCH-A475, SCH-A505, SCH-A509, SCH-A530, SCH-A539, SCH-A561, SCH-A563, SCH-A564, SCH-A591, SCH-A592, SCH-A595, SCH-A599, SCH-A610, SCH-A650, SCH-A670, SCH-A809, SCH-A890, SCH-NI81, SCH-NI82, SCH-NI91, SCH-NI95, SCH-N370, SCH-N375, SCH-X199, SCH-X209, SCH-X219, SCH-X309, SCH-X319, SCH-X359, SGH-A200, SGH-A288, SGH-A300, SGH-A308, SGH-A400, SGH-A408, SGH-A500, SGH-A608, SGH-C207, SGH-D100, SGH-D415, SGH-E105, SGH-E315, SGH-E316, SGH-E317, SGH-E400, SGH-E715, SGH-K258, SGH-N200, SGH-N288, SGH-N400, SGH-N500, SGH-N620, SGH-N625, SGH-N626, SGH-N628, SGH-N635, SGH-PI07, SGH-P408, SGH-Q200, SGH-Q208, SGH-Q300, SGH-R200, SGH-R208, SGH-R210, SGH-R220, SGH-R225, SGH-R225m, SGH-S307, SGH-T100, SGH-T108, SGH-T200, SGH-T208, SGH-T400, SGH-T408, SGH-T410, SGH-T500, SGH-V205, SGH-V206, SGH-X105, SGH-X425, SGH-X426, SGH-X427, Ace, E330N, E350, E370, IP-A790, MM-5600, SCH-A570, SCH-A720, SCH-A790, SCH-A795, SGH-A800, SGH-C100, SGH-C120, SGH-C200, SGH-C207, SGH-C210, SGH-C225, SGH-C300, SGH-C416, SGH-C417, SGH-D307, SGH-D347, SGH-D357, SGH-D406, SGH-D407, SGH-D410, SGH-D500, SGH-D500C, SGH-D500E, SGH-D508, SGH-D600, SGH-D600E, SGH-E100, SGH-E300, SGH-E310, SGH-E330, SGH-E330N, SGH-E335, SGH-E340, SGH-E340E, SGH-E350, SGH-E360, SGH-E370, SGH-E380, SGH-E600, SGH-E630, SGH-E635, SGH-E700, SGH-E710, SGH-E730, SGH-E760, SGH-E770, SGH-E800, SGH-P200, SGH-P207, SGH-P735, SGH-S300M, SGH-S400I, SGH-S401I, SGH-T209, SGH-T309, SGH-T319, SGH-T609, SGH-T619, SGH-T709, SGH-T719, SGH-V200, SGH-X100, SGH-X160, SGH-X200, SGH-X300, SGH-X460, SGH-X461, SGH-X475, SGH-X480, SGH-X495, SGH-X497, SGH-X506, SGH-X507, SGH-X510, SGH-X520, SGH-X530, SGH-X600, SGH-X620, SGH-X640, SGH-X650, SGH-X660, SGH-X670, SGH-X680, SGH-X680V, SGH-X700, SGH-X800, SPH-A420, SPH-A580, SPH-A640, SPH-A790, SPH-A920, SPH-M500, X660, Blade SPH-A900	A03	NI4FX
	SGH-D720, SGH-E620, SGH-E720, SGH-E810, SGH-i300, SGH-P730, SGH-Z130, SGH-Z140, SGH-Z300, SGH-Z500, SGH-ZV30	A60	N33FX
	C140, C170, D520, D800, D830, D840, D880, D900, D900i, E200, E250, E251, E390, E570, E590, E740, E870, J600, E900, E840, F210, F300, F330, F400, F480, F490, F700, G800, G810, i200, i450, i530, i560, i620, i600, i710, i780, J150, J700, L310, L320, L170, L770, M300, P300, U600, U700, U900, X820, X830, ZV60, ZV40, Z240, Z360, Z400, Z510, Z540, Z560, Z720	A131	N35GA
SFR	v1605	A53	N28FX
Sharp	GX25, 550SH, 703, 770SH, 902, 903, GX15, GX17, GX29, GX30, GX30i	A45	N25FX
	Willcom WS003SH, Willcom WS0075H	A79	N36FX
Skype	Netgear SPH101	A32	N20FX
SoftBank	X01HT	A53	N28FX

Manufacturer	Model	iGo Connectors	
Mobile Phone / PDAs		Order Code	
Sony Ericsson	D750i, J100a, J100c, J100i, J110i, J120i, J220a, J220c, J220i, J221, J230a, J230c, J230i, K200i, K220i, K310c, K310i, K320i, K510a, K510c, K510i, K530i, K550i, K550im, K610i, K610im, K750c, K750i, K758c, K790a, K790c, K800i, K810i, K850i, M600i, M608c, P1i, P990c, P990i, S500i, T250a, T250i, T650i, V630i, V2001, W200a, W200i, W300c, W300i, W550i, W580i, W600i, W610i, W660i, W700c, W700i, W710, W710c, W710i, W810, W810c, W810i, W850i, W880i, W910i, W950c, W960i, Z250i, Z310a, Z310i, Z320i, Z520a, Z520c, Z520i, Z525a, Z530c, Z530i, Z550, Z550a, Z550c, Z550i, Z558i, Z610i, Z710c, Z710i, Z750, Z750i, Walkman W550c, Walkman W600c, Walkman W600i, Walkman W800c, Walkman W800i, Walkman W900c, Walkman W900i, Walkman W950i	A64	N35FX
Sprint	PPC-6700, PPC-6800, HTC Mogul	A53	N28FX
SPV	C500, M500	A53	N28FX
Telecom New Zealand	Apache	A53	N28FX
Telus	P4000, UTStarcom PPC 6700	A53	N28FX
T-Mobile	Dash, MDA Pro, SDA, AMEO, MDA, MDA compact III, MDA Mail, MDA Vario, MDA Vario II, SDA Music, Wing	A53	N28FX
UTStarcom	XV6700, PPC6700	A53	N28FX
Verizon	VX6800, XV-6700	A53	N28FX
Vodafone	I210, VI240, VI415, vI605, VI640, V2140, VPA compact IV, VPA Compact II, VPA Compact s, VPA IV, VPA Compact III	A53	N28FX
VPA	Compact	A53	N28FX
XDA	mini, II Mini	A53	N28FX
Bluetooth Devices			
Jabra	A125s, BT620s	A32	N20FX
	A210, BT150, BT160, BT350, BT500, BT500v, BT800, JX10	A58	N32FX
	BT125, BT135, BT320, BT325s, BT5010, BT5020, BT8010	A130	N29GA
LG	HBM-500, HBM-500, HBM-730	A92	N38FX
Motorola	H3, H350, H500, H550, H605, H670, H700, T305, RAZRWIRE Mercury/Gray, RAZRWIRE Pewter/Black Iridium, RAZRWIRE Platinum/Gold Iridium, ROKR S9	A32	N20FX
	H800	A97	N34GA
Nextlink	Bluespoon AX	A58	N32FX
Nokia	HS-11W, HS-3W, BH-203, BH-204, BH-205, HDW-3, HS-11W, HS-12W, HS-21W, HS-4W, HS-53W, HS-54W, HS-55W, HS-56W	A95	N39FX
	BH-100, BH-200, BH-201, BH-202, BH-206, BH-207, BH-208, BH-300, BH-301, BH-301-LT, BH-302, BH-303, BH-500, BH-501, BH-600, BH-700, BH-700-BK, BH-700-VH, BH-701, BH-800, BH-800-BK, BH-800-VH, BH-801, BH-900, HS-26W, SU-27W Digital Pen	A105	N40FX
	Treo 650 wireless Headset	A43	N24FX
Plantronics	M2500	A39	N22FX
Sony Ericsson	HBH-DS970, HBH-GV435, HBH-IV835, HBH-PV700, HBH-PV705, Music Receiver MBR-100	A64	N35FX
Southwing	SA505	A32	N20FX
	SH440	A58	N32FX
Voice Star	VS600	A29	N18FX
MP3 / Satellite Radio			
Apple	iPod, iPod Classic, iPod Mini, iPod nano, iPod nano (PRODUCT) Red, iPod nano video, iPod Photo, iPod Touch, iPod U2 SE, iPod Video	A61	N34FX
	iPod Shuffle (2nd Generation)	A111	N42FX
Creative	ZEN 8GB, ZenStone	A32	N20FX
	Zen, MuVo 2, MuVo2 FM, Nomad Jukebox 2, Nomad Jukebox 3, Nomad Jukebox Zen NX, Nomad Jukebox Zen USB 2.0, Nomad Jukebox Zen Xtra, Zen Portable Media Center, Zen Touch	A79	N36FX
Insignia	NS-DV2G, NS-DV4G, NS-DVB4G, Sport NS-DA1G, Sport NS-DA2G	A29	N18FX
Jens of Sweden	MP-400, MP-450, MP-X	A29	N18FX
Motorola	m500	A32	N20FX
Rio	Carbon, ce2100	A29	N18FX

Manufacturer	Model	iGo Connectors	
MP3 / Satellite Radio		Order Code	
Samsung	NeXus 25 YP-X5X, NeXus 50YP-X5Z	A29	N18FX
Sony	Walkman NW-E405, Walkman NW-E407, Walkman NW-E507, Walkman NW-S205F	A29	N18FX
	Walkman NW-S205F	A32	N20FX
Toshiba	MEU202-SL	A29	N18FX
	MEU202-SL	A32	N20FX
	gigabeat MEG-F10K, gigabeat MEG-F10L, gigabeat MEG-F10S, gigabeat MEG-F20K, gigabeat MEG-F20S, gigabeat MEG-F40S, gigabeat MEG-F60S, gigabeat MES30VK, gigabeat MES30VW, gigabeat MES60VK, gigabeat MEV30K	A54	N29FX
VuGo	VuGo	A95	N39FX
Gaming / GPS			
Garmin	Edge 205, Edge 305, Forerunner 205, Forerunner 301, Forerunner 305	A32	N20FX
	Forerunner 205, Forerunner 305, nuvi 200, nuvi 250, nuvi 270, nuvi 300, nuvi 310, nuvi 350, nuvi 360, nuvi 370, nuvi 650, nuvi 660, nuvi 670, nuvi 680, Quest , Quest 2, StreetPilot c330, StreetPilot c340, StreetPilot c550, StreetPilot i2, StreetPilot i3, StreetPilot i5	A53	N28FX
HP	iPAQ Travel Companion rx5915	A32	N20FX
Mio	Digi Walker 168, Digi Walker 268, Digi Walker 268+, Digi Walker 269, Digi Walker 269+, Digi Walker 336BT, Digi Walker 336g, Digi Walker 336i, Digi Walker 339, Digi Walker 8390, Digi Walker 8870, Digi Walker A201, Digi Walker A701, Digi Walker C230, Digi Walker C320, Digi Walker C510, Digi Walker C510E, Digi Walker C710, Digi Walker P350, Digi Walker P550, DigiWalker C220, DigiWalker C310x, DigiWalker C520, DigiWalker H610	A32	N20FX
Nintendo	DS, Gameboy Advance SP	A13	N16FX
	DS Lite	A88	N37FX
Nokia	LD-1W	A95	N39FX
Sony	PlayStation Portable	A54	N29FX
	Nav-U NV-U52, Nav-U NV-U70, Nav-U NV-U71T, Nav-U NV-U72T, Nav-U NV-U82, Nav-U NV-U92T	A79	N36FX
TomTom	Go 520, Go 720, One , ONE XL, ONE XL Europe, ONE XL Regional, ONE Europe, ONE Regional	A32	N20FX
	GO, GO 300, GO 500, GO 510, GO 700, GO 710, GO 900, GO 910, MOBILE 5, NAVIGATOR 5, NAVIGATOR 6, RIDER , RIDER 2nd edition	A79	N36FX
Gaming / GPS			
HP	PhotoSmart R927	A79	N36FX
Kodak	EasyShare picture viewer	A29	N18FX
	M753, M853, P850, P880, V530, V570, V705, V803, Z730, Z7590, Z760, EasyShare P712, EasyShare V550, EasyShare V603, EasyShare V610, EasyShare-One	A79	N36FX

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Acer	Aspire 5570z, Aspire 5580-6432	Notebook Tip 02
	AcerNote 367D, AcerNote 367T, AcerNote 390, Anywhere I100LX, Anywhere I120LX, Extensa 366D, Extensa 367D, Extensa 367T, Extensa 368D, Extensa 391C, Extensa 391T, Extensa 392C, Extensa 392T, Extensa 393, Extensa 393C, Extensa 393T, Extensa 394T, Extensa 395T, Extensa 900, Extensa 900CDT, Extensa 900T, Extensa Ess3-391T,	Notebook Tip 03
	Aspire 1200, Aspire 1642z, Aspire 1680, Aspire 1683WLMi, Aspire 1690, Aspire 2000, Aspire 2001LCi, Aspire 2002LCi, Aspire 2002LMi, Aspire 2003LMi, Aspire 2010, Aspire 2012WLCi, Aspire 2012WLMi, Aspire 2020, Aspire 2025WLMi, Aspire 3000, Aspire 3000LC, Aspire 3002LMi, Aspire 3003WLMi, Aspire 3022WLMi, Aspire 3050-1047, Aspire 3050-1594, Aspire 3613, Aspire 3614WLMi, Aspire 3618AWLCi, Aspire 3622WXCi, Aspire 3623NVXMi, Aspire 3623WLCi, Aspire 3623WLMi, Aspire 3623WXCi, Aspire 3623WXMi, Aspire 3624WXCi, Aspire 3624WXMi, Aspire 3634WLMi, Aspire 3680-2022, Aspire 3680-2633, Aspire 3690-2710, Aspire 3693WLMi, Aspire 5002WLMi, Aspire 5003WLMi, Aspire 5024, Aspire 5050-3785, Aspire 5050-5278, Aspire 5100, Aspire 5100-3357, Aspire 5100-3577, Aspire 5100-3583, Aspire 5100-3825, Aspire 5100-3949, Aspire 5100-3959, Aspire 5100-5328, Aspire 5100-5540, Aspire 5100-5840, Aspire 5100-5873, Aspire 5101WLMi, Aspire 5102WLMi, Aspire 5512WLMi, Aspire 5513EWLM, Aspire 5514WLMi, Aspire 5514WXMi, Aspire 5570-2067, Aspire 5570-2609, Aspire 5570-2758, Aspire 5570-2792, Aspire 5570-2935, Aspire 5570-4421, Aspire 5672WLMi, Aspire 5680-6509, Extensa 2300, Extensa 3000, Ferrari 1004WTMi, Tablet TMC104TCi, Tablet TMC110TCi, Tablet TMC110Ti, TravelMate 222X, TravelMate 223X, TravelMate 225X, TravelMate 225XC, TravelMate 225XV-PRO, TravelMate 2300, TravelMate 2301LC, TravelMate 2301LCi, TravelMate 2301WLCi, TravelMate 2301XC, TravelMate 2303LC, TravelMate 2303LCi, TravelMate 2303WLCi, TravelMate 2304LCi, TravelMate 2304WLCi, TravelMate 2305, TravelMate 230X, TravelMate 230XC, TravelMate 230XV, TravelMate 230XV-PRO, TravelMate 2310, TravelMate 233LC, TravelMate 233X, TravelMate 233XV, TravelMate 233XVi, TravelMate 234LCi, TravelMate 2350, TravelMate 2400, TravelMate 2410, TravelMate 2423WXMi, TravelMate 2440, TravelMate 2450, TravelMate 2460, TravelMate 2470, TravelMate 2480, TravelMate 2480-2153, TravelMate 2480-2551, TravelMate 2480-2705, TravelMate 2480-2779, Travelmate 2482WXMi, TravelMate 261XC, TravelMate 261XV, TravelMate 272LC, TravelMate 272XV, TravelMate 273LC, TravelMate 273XV, TravelMate 281XC, TravelMate 281XV, TravelMate 283LC, TravelMate 283LCi, TravelMate 283XV, TravelMate 283XVi, TravelMate 290, TravelMate 292, TravelMate 3000, TravelMate 3002WTMi, TravelMate 3004VVTMi, TravelMate 3010, TravelMate 3020, TravelMate 3030, TravelMate 3040, TravelMate 3200, TravelMate 3210, TravelMate 3220, TravelMate 3230, TravelMate 3250, TravelMate 3260, TravelMate 3270, TravelMate 3270-6569, TravelMate 3300, TravelMate 350TE, TravelMate 350TE-N, TravelMate 351TE-N, TravelMate 351TEV, TravelMate 351TEV-D, TravelMate 351TEV-N, TravelMate 353TEV, TravelMate 354TEV, TravelMate 380, TravelMate 4000, TravelMate 4000LCi, TravelMate 4000WLCi, TravelMate 4001LCi, TravelMate 4001WLCi, TravelMate 4001WLMi, TravelMate 4002WLMi, TravelMate 4010, TravelMate 4020, TravelMate 4050, TravelMate 4060, TravelMate 4070, TravelMate 4080, TravelMate 4100, TravelMate 4101WLMi, TravelMate 4150, TravelMate 4500, TravelMate 4501WLMi, TravelMate 4502LMi, TravelMate 4600, TravelMate 4604WLMi, TravelMate 4650, TravelMate 6000, TravelMate 6003LMi, TravelMate 6020, TravelMate 6030, TravelMate 6050, TravelMate 6050NT, TravelMate 610TXVi, TravelMate 610TXVi-Me, TravelMate 611TXCi, TravelMate 611TXCi-D, TravelMate 611TXV, TravelMate 612TXCi, TravelMate 612TXV, TravelMate 613TXV, TravelMate 614TXCi, TravelMate 630XCi, TravelMate 630XV, TravelMate 632XCi, TravelMate 633LCi, TravelMate 634XCi, TravelMate 636LCi, TravelMate 661LCi, TravelMate 662LMi, TravelMate 730TXV, TravelMate 732TLV, TravelMate 732TXV, TravelMate 734TL, TravelMate 734TXV, TravelMate 735TLV, TravelMate 736TL, TravelMate 736TLV, TravelMate 737TLV, TravelMate 738TLV, TravelMate 739GTLV, TravelMate 739TLV, TravelMate 740LVF, TravelMate 741LVF, TravelMate 744LCF, TravelMate 8000, TravelMate 8002LCi, TravelMate 8003LMi, TravelMate 8006LMi, TravelMate 800LCi, TravelMate 800XCi, TravelMate 802LCi, TravelMate 803LCi, TravelMate 804LMi, TravelMate 8100, TravelMate 8100A, TravelMate 8103WLMi, TravelMate 8104WLMi, TravelMate C110, TravelMate C110CTi, TravelMate C110Ti, TravelMate C111TCi, TravelMate C111Ti, TravelMate C112TCi, TravelMate C112Ti, TravelMate C113TCi, TravelMate C113Ti, TravelMate C200, TravelMate C210, TravelMate C300, TravelMate C301XCi, TravelMate C301XCi-G, TravelMate C301XCi-G-SP, TravelMate C302XCi, TravelMate C302XMi, TravelMate C303XMi, TravelMate C310, TravelMate TM279, TravelMate TM360, TravelMate TM370, TravelMate TM380, TravelMate TM520, TravelMate TM530, TravelMate TM620, TravelMate TMC110, TravelMate TMC113LCi	Notebook Tip 14
Act	P-88T	Notebook Tip 03
Advent	7240, DVD7365	Notebook Tip 02
AECOlympia	LT386SX	Notebook Tip 03
AIM	Green 759	Notebook Tip 03
Alcam	LX-601, N600-MT2, N600-MT3, XL-663	Notebook Tip 12
Alienware	Sentia M3200, Sentia M3400, Sentia M3450	Notebook Tip 03
Allegro	L7200 6/C300	Notebook Tip 02
Altima	Maestro P79R	Notebook Tip 02
AMS Tech	Rodeo 1000CT, Rodeo 1000CX, Rodeo 1010CT, Rodeo 1010CX, Rodeo 1010CXNT, Rodeo 7000, Rodeo 7030ECX, Rodeo 7620, Rodeo 7630ECXDNT, Rodeo 7640XL, TravelPro 180, TravelPro 1900	Notebook Tip 03
APT	Green 795	Notebook Tip 03
Arm	I100, TS30i2, TS30W, TS795, ArmNote N30W, Green 759	Notebook Tip 03
	TS5027MX	Notebook Tip 11
Aspen	6200D	Notebook Tip 03
AST	Advantage Exp 212, Advantage Exp 486DX4/100, Advantage Exp XL	Notebook Tip 11
	A, J, M	Notebook Tip 12

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Asus	A1 Series, F7 Series, F7000, L1 Series, L7 Series, L7000, L7000C, L7200, L7300, L8 Series, M1 Series, M5 , M5N, M8 Series, S1 Series, S200, S200N, S300N, S5, S5N, S8 Series, T9 Series, M5200N, S5200N, Grandio F7400	Notebook Tip 02
AT&T	Globalyst 130, Globalyst 520, Safari 3140	Notebook Tip 06
	Globalyst 200S, Safari 3152	Notebook Tip 11
Atasi	1100, 1200, 900	Notebook Tip 03
Averatec	3120V, 3150H, 3150HD, 3150HS, 3150HW, 3150P, 3200, 3220H, 3220HI, 3225HS, 3250HI, 3250HX, 5100, 5110H, 5110HX, 5110P, 6240, AV3500T60, AV6200H60, AV6210HX80, AV6210X60, 1150-EV1, 2150-EH1, 2155-EH1, 2225-EH1, 2260-EH1, 2260-EK1, 2260-EY1, 2370HM1E-1, AV1050-EB1, AV1050-EU1, AV1150-AW1, AV3250HS, AV3250PX, AV3255P1, AV3270-EE1, AV3270-EH1, AV3320-EH1, AV3360EG1, AV3360EH1, AV3500T80, AV3715-ED1, AV3715-EH1, AV4115-EE1, AV4155-EH1, AV4265-EH1, AV4270-EH1, AV5500, AV6110-EH1, AV6235	Notebook Tip 03
BenQ	Joybook 5000, Joybook 5100, Joybook 5100N, Joybook 5100U, Joybook 5120, Joybook 6000, Joybook 7000, Joybook A82, Joybook S52, Joybook S52E, Joybook S53, Joybook S53W, Joybook S72	Notebook Tip 02
Bondwell	486	Notebook Tip 06
BSI	6200D	Notebook Tip 03
Canon	InnovaBook 300, InnovaBook 400	Notebook Tip 03
CardStar	486DX	Notebook Tip 12
Chaplet	1100, iLufa 800, iLufa 820	Notebook Tip 03
	ILufa 580, ILufa 580SX, ILufa 780	Notebook Tip 06
Chem USA	ChemBook 7200	Notebook Tip 02
	ChemBook 1100, ChemBook 6200D, ChemBook N30W	Notebook Tip 03
Chicony	6200	Notebook Tip 03
Clevo	862, 86CE, 98	Notebook Tip 03
Commadore	PI00, Featron 6000	Notebook Tip 03
Commax	6200D, NB8600	Notebook Tip 03
Compal	N30B2, N30W, N32NC, TS30H, TS30I , TS30I3, TS30T, TS30T3, TS30W	Notebook Tip 03
Compaq	NC4000, NC4010, NC6000, NC6220, NC6230, NC8000, NW8000, NX7000, NX7010, NC4200, NC6120, NC6200, NX5000, NX6100, NX6110, NX6115, NX6120, NX6125, NX7200, TC4200, V3000, V3000z, V3016US, Armada 110, Armada E500, Armada E500S, Armada E700, Armada M300, Armada M700 , Armada V300 , Business Notebook NX6120, Business Notebook NX9020, Business Notebook NX9030, Business Notebook NX9040, Evo N110, Evo N150, Evo N200, Evo N400c, Evo N410c, Evo N600c, Evo N610c, Evo N620c, Evo N800c, Evo N800v, Evo N800w	Notebook Tip 02
	Presario Range – 2200, 2200LA, 2201US, 2202AL, 2203AL, 2203AP, 2203US, 2204AL, 2204AP, 2204US, 2205AL, 2205AP, 2206AL, 2206AP, 2207AP, 2208AP, 2209AP, 2209CL, 2210AP, 2210CA, 2210US, 2211AP, 2212AP, 2213AP, 2214AP, 2215AP, 2216AP, 2217AP, 2218AP, 2218RS, 2219AP, 2220AP, 2221AP, 2222AP, 2223AP, 2223US, 2224AP, 2225AP, 2226AP, 2226CL, 2227AP, 2227US, 2228AP, 2229AP, 2230AP, 2231AP, 2231US, 2232AP, 2232US, 2233AP, 2234AP, 2235AP, 2236AP, 2237AP, 2238AP, 2239AP, 2240AP, 2241AP, 2242AP, 2243AP, 2244AP, 2245AP, 2246AP, 2248AP, 2249AP, 2250AP, 2251AP, 2252AP, 2253AP, 2254AP, 2255AP, 2256AP, 2258AP, 2259AP, 2260AP, 2261AP, 2800US, 2801EA, 2802EA, 2803EA, 2804EA, 2805US, 2806AP, 2807EA, 2809FR, 2810CA, 2811CL, 2812EA, 2813AU, 2814AP, 2815LA, 2816EA, 2817AR, 2818AP, 2819AP, 2820AP, 2821SC, 2822AP, 2823AP, 2825AP, 2826TC, 2827AP, 2828AP, 2830EA, 2832AP, 2835AP, 2838AP, 2840TC, 2845AP, 2853AP, 2857AP, 2858AP, 2860AP, 2861AP, 2862AP, 2863AP, 2864AP, 2865AP, 2866AP, 2867AP, 2868AP, 2869AP, 2870AP, 2871AP, 2887AP, 2888AP, 2890AP, 2891AP, 2892AP, 2893AP, 2894AP, 2895AP, 2896AP, 2897AP, 2898AP, 2899AP, 2900, 2902, 2903, 2904, 2905, 2906, 2907, 2908, 305, B3800, C300EA, C300EU, C302NR, C303NR, C304NR, C306US, C307NR, C310EA, C310EU, C350EA, C350EU, C500EA, C500EU, C501NR, C501TU, C502CA, C502EA, C502EU, C502TU, C502US, C503TU, C503WV, C504EA, C504EU, C504TU, C504US, C506CA, C506TU, C507US, C508US, C509NR, C518LA, C540EA, C542EA, C551NR, C551TU, C552CA, C552TU, C552US, C553TU, C554TU, C554US, C555EA, C555EU, C555TU, C556CA, C556TU, C557CL, C557TU, C558TU, C559TU, C560TU, C561TU, C562TU, C563TU, C564TU, C565TU, C566TU, C567TU, C570EA, C571, F502EA, F502EU, F504EA, F545EA, F545EU, F555US, F557US, F572US, F730us, M2000, M2000Z, M2001AL, M2001AP, M2001EA, M2001XX, M2002AL, M2002AP, M2003AL, M2003AP, M2004AP, M2005AP, M2005US, M2006AP, M2007AP, M2008AP, M2009AP, M2010AP, M2010CA, M2010EA, M2010US, M2011AP, M2011EA, M2012AP, M2013AP, M2014AP, M2015AP, M2015LA, M2016AP, M2017AP, M2018AP, M2019AP, M2019EA, M2020AP, M2020EA, M2021AP, M2022AP, M2023AP, M2024AP, M2025AP, M2026AP, M2027AP, M2028AP, M2029AP, M2030AP, M2030EA, M2031AP, M2031EA, M2032AP, M2033AP, M2034AP, M2034EA, M2035AP, M2035EA, M2036AP, M2037AP, M2038AP, M2039AP, M2040AP, M2041AP, M2042AP, M2043AP, M2044AP, M2045AP, M2046AP, M2046EA, M2047AP, M2048AP, M2049AP, M2050EA, M2051AP, M2052AP, M2052EA, M2053AP, M2054AP, M2054EA, M2055AP, M2055EA, M2065EA, M2070EA, M2070US, M2071EA, M2075EA, M2099XX, M2101EA, M2101US, M2105CA, M2105EA, M2105US, M2108EA, M2108US, M2113EA, M2125EA, M2130EA, M2131EA, M2150EA, M2175EA, M2200, M2201AP, M2201EA, M2201TU, M2202AP, M2202TU, M2203AP, M2204AP, M2205AP, M2205EA, M2206AP, M2207AP, M2207EA, M2208AP, M2209AP, M2210AP, M2211AP, M2212AP, M2213AP, M2214AP, M2215AP, M2215EA, M2215LA, M2216AP, M2217AP, M2217LA, M2218AP, M2219AP, M2220AP, M2221AP, M2222AP, M2223AP, M2224AP, M2225AP, M2226AP, M2227AP, M2228AP, M2229AP, M2230AP, M2231AP, M2232AP, M2233AP, M2234AP, M2235AP, M2236AP, M2237AP, M2238AP, M2239AP, M2240AP, M2241AP, M2241EA, M2242AP, M2243AP, M2244AP, M2245AP, M2245EA, M2299XX MV IUR, M2301NR, M2305NR, M2401XT,	Notebook Tip 02

Laptops / Notebooks

Compaq

Presario Range –
 V1000, V1001AP, V1002AP, V1003AP, V1004AP, V1005AP, V1006AP, V1007AP, V1008AP, V1009AP, V1010AP, V1011AP, V1012AP, V1013AP, V1014AP, V1015AP, V1016AP, V1017AP, V1018AP, V1019AP, V1020AP, V1021AP, V1022AP, V1023AP, V1024AP, V1025AP, V1026AP, V1027AP, V1028AP, V1029AP, V1030AP, V1031AP, V1032AP, V1033AP, V1034AP, V1035AP, V1036AP, V1037AP, V1038AP, V1039AP, V1040AP, V1041AP, V1042AP, V1043AP, V1044AP, V1045AP, V1046AP, V1047AP, V1048AP, V1049AP, V1050AP, V1051AP, V1052AP, V1053AP, V1054AP, V1055AP, V1056AP, V1057AP, V1058AP, V1059AP, V1060AP, V1061AP, V1062AP, V1063AP, V1064AP, V1065AP, V1066AP, V1067AP, V1068AP, V1069AP, V1070AP, V1071AP, V1072AP, V1073AP, V1074AP, V1075AP, V1101AP, V1102AP, V1103AP, V1104AP, V1105AP, V1106AP, V1107AP, V1108AP, V1109AP, V1110AP, V1111AP, V1112AP, V1113AP, V2000, V2001AP, V2002AP, V2003AP, V2004AP, V2005AP, V2006AP, V2007AP, V2008AP, V2009AP, V2010AP, V2010US, V2011AP, V2012AP, V2013AP, V2014AP, V2015AP, V2016AP, V2017AP, V2018AP, V2019AP, V2020AP, V2021AP, V2022AP, V2024AP, V2025AP, V2026AP, V2027AP, V2028AP, V2029AP, V2030AP, V2030US, V2031AP, V2032AP, V2033AP, V2034AP, V2035AP, V2036AP, V2042AP, V2069CL, V2100, V2110US, V2135US, V2140CA, V2140US, V2205US, V2220US, V2300, V2300T, V2300Z, V2304US, V2305CA, V2305US, V2306US, V2309US, V2310CA, V2310US, V2311AP, V2311US, V2312US, V2321US, V2335US, V2398XX MV IUR, V2399XX , V2400T, V2403NR, V2404US, V2405CA, V2405US, V2409US, V2410CA, V2410CL, V2410US, V2413US, V2414NR, V2415LA, V2419US, V2424NR, V2552US, V2555US, V2565US, V2570CA, V2570NR, V2575US, V2582US, V2606CU, V2607CA, V2608CA, V2608WM, V2610CA, V2610US, V2615US, V2630US, V2665US, V2665US, V2670US, V2710CA, V2710US, V3000T, V3010CA, V3010US, V3015CA, V3015NR, V3018US, V3019US, V3020CA, V3020US, V3030CA, V3200, V3200TU, V3201AU, V3201TU, V3202AU, V3202TU, V3203AU, V3203TU, V3204AU, V3204TU, V3205TU, V3206TU, V3207TU, V3208TU, V3211TU, V3218TU, V3219TU, V3239AU, V3239TU, V3240AU, V3243TU, V3244TU, V3250TU, V3255TU, V3256TU, V4000, V4000xx MV IUR, V4001AP, V4002AP, V4002xx MV IUR, V4003AP, V4003xx MV IUR, V4004AP, V4004xx MV IUR, V4005CL, V4005xx , V4015US, V4020US, V4025US, V4035CA, V4035EA, V4035US, V4040EA, V4050EA, V4055EA, V4058EA, V4060EA, V4075EA, V4100, V4101AP, V4102AP, V4103AP, V4104AP, V4105AP, V4106AP, V4107AP, V4108AP, V4109AP, V4110AP, V4110EA, V4111AP, V4112AP, V4113AP, V4114AP, V4115AP, V4116AP, V4117AP, V4118AP, V4119AP, V4120EA, V4120TU, V4121TU, V4122TU, V4130EA, V4133EA, V4135US, V4144EA, V4145EA, V4146EA, V4147EA, V4160EA, V4201TU, V4202TU, V4203EA, V4205EA, V4215EA, V4240US, V4310NR, V4325CA, V4325US, V4332US, V4435NR, V4440US, V5000, V5000T, V5005CA, V5005US, V5015US, V5099XX, V5100, V5100Z, V5101US, V5102NR, V5105CA, V5105US, V5108CU, V5115US, V5119US, V5120NR, V5160US, V5200, V5201CA, V5201US, V5204NR, V5205NR, V5206OM, V5207NR, V5208CA, V5209US, V5210CA, V5210US, V5214EA, V5215EA, V5216EA, V5233EA, V5234EA, V5235EA, V5236EA, V5245EU, V5303NR, V5304US, V5305WM, V5306US, V5307US, V5308US, V5310US, V5315WM, V6000, V6000T, V6000T, V6000Z, V6001AU, V6002AU, V6003AU, V6030US, V6101EU, V6101US, V6105EA, V6105NR, V6107US, V6110CA, V6110US, V6120US, V6126EU, V6130US, V6133EU, V6137US, V6205NR, V6210CA, V6210US, V6215CA, V6230CA, V6254EA, V6310CA, V6310US, V6320CA, V6325EA, X1000, X1001US, X1005LA, X1006EA, X1007EA, X1010AL, X1010CA, X1010EA, X1010US, X1011AL, X1012, X1012AL, X1012EA, X1012QV, X1015US, X1016EA, X1018CL, X1020EA, X1020US, X1021AP, X1022AP, X1023AP, X1026AP, X1027AP, X1028AP, X1028CL, X1029AP, X1030US, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1038AP, X1040AP, X1040US, X1041AP, X1042AP, X1043AP, X1044AP, X1045AP, X1046AP, X1047AP, X1048AP, X1049AP, X1050AP, X1050CA, X1050US, X1051AP, X1052AP, X1053AP, X1054AP, X1055AP, X1056AP, X1057AP, X1058AP, X1058CL, X1060AP, X1061AP, X1062AP, X1063AP, X1064AP, X1065AP, X1066AP, X1067AP, X1068AP, X1069AP, X1070AP, X1071AP, X1072AP, X1073AP, X1074AP, X1075AP, X1076AP, X1077AP, X1078AP, X1079AP, X1080AP, X1081AP, X1082AP, X1083AP, X1084AP, X1085AP, X1086AP, X1087AP, X1088AP, X1089AP, X1090AP, X1091AP, X1092AP, X1093AP, X1094AP, X1095AP, X1096AP, X1097AP, X1098AP, X1099AP, X1105EA, X1110EA, X1115EA, X1140EA, X1155EA, X1200, X1201AP, X1201US, X1202AP, X1203AP, X1204AP, X1205AP, X1206AP, X1207AP, X1208AP, X1209AP, X1210AP, X1210CA, X1210US, X1211AP, X1212AP, X1213AP, X1214AP, X1215AP, X1216AP, X1217AP, X1218AP, X1219AP, X1220AP, X1220EA, X1220US, X1221AP, X1222AP, X1223AP, X1224AP, X1225AP, X1227AP, X1228AP, X1229AP, X1230AP, X1230US, X1231AP, X1232AP, X1233AP, X1234AP, X1236AP, X1237AP, X1238AP, X1239AP, X1240AP, X1241AP, X1242AP, X1300, X1301AP, X1301US, X1302AP, X1303AP, X1304AP, X1305AP, X1306AP, X1307AP, X1308AP, X1309AP, X1310AP, X1311AP, X1312AP, X1313AP, X1314AP, X1315AP, X1316AP, X1317AP, X1318AP, X1319AP, X1320AP, X1321AP, X1322AP, X1324AP, X1325AP, X1326AP, X1327AP, X1328AP, X1330AP, X1360CL, X1360US, X1370US, X1390US, X1460CA, X1460US, X1480US, X1480XX, ZT3000LA

Prosignia 170, Prosignia 190, Tablet TC-1000, Tablet TC-1100

Evo N115, Evo N160, Evo N180

Presario Range –
 I010, I020, I030, I060, I065, I070, I075, I080US, I200AN, I200AP, I200CA, I200CL, I200EA, I200SC, I200T-I2XL, I200TC, I200TH, I200US, I201AP, I201EA, I201S, I202EA, I203CL, I205EA, I206R, I207, I210, I210JP, I210LA, I211CA, I211EA, I211LA, I212CL, I212EA, I213CL, I213EA, I214EA, I214FR, I214SR, I215, I216JP, I216US, I217JP, I219JP, I220, I232ES, I234, I235, I236, I237, I238, I240, I242, I244, I245, I246, I247, I250, I252, I255, I256, I257, I260, I262, I266, I267, I270, I272, I273, I274, I275, I277, I278, I279, I2XL, I2XL300B, I2XL400, I2XL401, I2XL404, I2XL410, I2XL420, I2XL423, I2XL426, I2XL427, I2XL430, I2XL500, I2XL501, I2XL504, I2XL505, I2XL526, I2XL527, I400T, I4XL240, I600S, I610, I611, I621, I622, I625, I626, I645, I655, I670, I680, I681, I682, I685, I687, I688, I690, I692, I693, I694, I6XL, I700T, I700US, I701AK, I702AP, I703KR, I704KR, I705AP, I710T, I711CL, I712US, I713EA, I714EA, I715EA, I716EA, I717RSH, I720, I721EA, I722US, I723AP, I724TC, I725TC, I726TC, I7XL260, I800t , I800US, I800XL180, I8XL280, I700T, I700TC, I700US, I701TV, I701US, I702EA, I710CA, I710EA, I710SC, I710TC, I710US, I711AP, I711EA, I711TC, I712EA, I715EA, I716EA, I720US, I701CL, I702US, I703AP, I704JP, I705US, I706EA, I709EA, I710TC, I711EA, I712EA, I713EA, I714EA, I715EA, I716EA, I717RSH, I718EA, I719EA, I720US, I721EA, I722EA, I723EA, I724EA, I725EA, I726EA, I727EA, I728EA, I729EA, I730CA, I731US, I732US, I733, I734RSH, I735CA, I736, I737EA, I738EA, I739EA, I800T, I801, I802, I803, I805

Prosignia 150

Notebook Tip 02

Notebook Tip 03

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
ComputerBook	6200T	Notebook Tip 03
Consul	98	Notebook Tip 03
CTX	CD, FC2A300, FC2A300A, FC3A300, Megapro 486, EZBook 330F, EZBook 390T, EZBook 400, EZBook 486, EZBook 500, EZBook 600, EZBook 700, EZBook 800, EZBook 893-T-FK	Notebook Tip 03
DEC	HiNote VP 700	Notebook Tip 03
	HPCP-12, PC 320, PC 325P	Notebook Tip 06
	PC 320P	Notebook Tip 11
Delcomp Allistra	6200D	Notebook Tip 03
Dell	Inspiron 1200, Inspiron 1300, Inspiron 2200, Inspiron 3000, Inspiron 3200, Inspiron 3500, Inspiron 7000, Inspiron B120, Inspiron B130, Latitude 110L	Notebook Tip 03
	Inspiron 1420 (Intel Graphic card), Inspiron 1501, Inspiron 1520 (Intel Graphic card), Inspiron 1720 (Intel Graphic card), Inspiron 300M, Inspiron 500M, Inspiron 510M, Inspiron 6000, Inspiron 600M, Inspiron 630M, Inspiron 640m, Inspiron 700M, Inspiron 710M, Inspiron E1405, Latitude 131L, Latitude ATG, Latitude ATG D630, Latitude D400, Latitude D410, Latitude D420, Latitude D430, Latitude D500, Latitude D505, Latitude D510, Latitude D520, Latitude D600, Latitude D610, Latitude D620 (Intel Graphic card), Latitude D630 (Intel Graphic card), Latitude X1, Latitude X300, Precision M20, Vostro 1000, Vostro 1400 (Intel Graphic card), Vostro 1500 (Intel Graphic card), XPS M1210, XPS M1330, XPS M140	Notebook Tip 35
DigiBook	1100, Wizard	Notebook Tip 03
DTK	Multimedia 86, Top-5A	Notebook Tip 03
Dual Tech	AIO-6200	Notebook Tip 03
E-Machines	Eslate 400K, Eslate 450K	Notebook Tip 03
EPS	P75, Pentium 120	Notebook Tip 03
Epson	ActionNote 800, ActionNote 910C	Notebook Tip 03
Escom	P100	Notebook Tip 03
	SubNotebook DX2/66	Notebook Tip 06
Everex	StepNote Plus, ExpressNote 586, StepNote 3500, StepNote KR3200VV, StepNote NC1500, StepNote NC1501, StepNote NC1502, StepNote NC1503, StepNote NM3500VV, StepNote NM3900VV, StepNote VA4100M, StepNote VA4101M, StepNote VA4103M, StepNote VA4103VV	Notebook Tip 03
Evesham Micros	Vale Voyager II	Notebook Tip 03
Featron	FT6000E	Notebook Tip 03
FIC	A420, A430, A440, A450	Notebook Tip 03
Fosa	6200D	Notebook Tip 03
Fujitsu	LifeBook Range – A1010, Amilo L, C1010, C1020, C1110, C1211D, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, C2340, C6637, C6xx5, Cxxx7, E2010, E4010, E4010D, E6624, E6634, E6644, E6654, E6664, E66xx, E7010, E7110, E8010, E8010D, E8020, S7010, S7010D, S7011, S7110, T4010, T4010D, T4020	Notebook Tip 03
	Celsius Mobile H	Notebook Tip 11
	FMV-BIBLO Range – FLX2H, LOOX S80B, LOOX S80B/W, LOOX S80C, LOOX S80C/W, LOOX T50E, LOOX T50E/W, LOOX T50G/W, LOOX T50H, LOOX T50J, LOOX T50K, LOOX T55G, LOOX T70E, LOOX T70G, LOOX T70H, LOOX T70HN, LOOX T70J, LOOX T70JN, LOOX T70K/T, LOOX T93B, LOOX T93B/W, LOOX T93C, LOOX T93C/W, MG12B, MG12B/C, MG12B/M, MG12C, MG12C/M, MG12D, MG13D, MG17D/A, MG50E, MG50G, MG50H, MG50HN, MG50K, MG50K/T, MG55E, MG70E, MG70E/ST, MG70G, MG70G/ST, MG70H, MG70K/T, MG75E, MG75G, MG75H, MG75H/ST, MG75HN, MG75K, MRI6B, NB14B, NB14B/R, NB15B, NB15B/S, NB15B/T, NB16B, NB16B/M, NB16C, NB16C/A, NB16C/R, NB16C/ST, NB16C/T, NB16C/V, NB16CA, NB16CR, NB18B, NB18C, NB18C/T, NB18D, NB18D/D, NB18D/F, NB18D/L, NB18D/V, NB19D, NB19D/D, NB50E, NB50G, NB50H, NB50HN, NB50J, NB50JN, NB50K, NB53E, NB55E, NB55E/T, NB55G, NB55G/T, NB55H, NB55H/T, NB55J, NB55J/T, NB55K, NB55K/T, NB70E, NB70E/T, NB70G, NB70H/T, NB75G, NB75G/T, NB75H, NB75H/T, NB75HN, NB75HN/T, NB75J, NB75K/T, NB80J, NB80JN, NB80K, NB90J/T, NB90J/TS, NB90JN/T, NB90K/T, NB90K/TS, NB90KN/T, NH24C, NH24D, NH26C, NH28D, NH50E, NH70E, NH90E/T, NU, RS18D, RS18D/D, RS18D/ST, RS18D/T, RS50E/T, RS55E/T	Notebook Tip 11
	LifeBook Range – 270Dx, 280Dx, 420D, 435Dx, 500, 520D, 520T, 530T, 531T, 535Tx, 555T, 565Tx, 585Tx, 585Tx1, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 675Tx, 690Tx, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B2175, B245x, B2545, B2562, B2566, B256x, B2610, B2620, B2630, B3010D, B3020, B3020D, B5010, B6110D, B6210, B6220, C340, C350, C352, C353, C360, C4120, C4235, C5130, C5235, C6177, C6320, C6330, C6525, C6535, C6537, C6547, C6556, C6557, C6577, C6581, C6591, C6611, C6631, C6651, C7631, C7651, C7661, E2010, E330, E335, E340, E342, E350, E351, E360, E362, E370, E380, E5140, E5320, E5520, E6150, E6520, E6530, E6540, E6541, E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595, Exxx5, L440, L470, P1000, P1032, P1035, P1110, P1120, P1510D, P1610, P2000, P2040, P2046, P2110, P2120, P5010, P5010D, P5020, P5020D, P7010, P7010D, P7120, P7120D, P7230, Q2010, S2010, S2020, S2110, S4510, S4542, S4546, S4572, S5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6230, S6231, S6240, Stylistic CT2020, T3010, T3010D	Notebook Tip 11
Stylistic Range – 3400, 3500, ST4110, ST4110P, ST4120, ST4120P, ST4121, ST5010, ST5010D, ST5011, ST5011D, ST5020, ST5020D, ST5021, ST5021D, ST5022, ST5022D, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, ST5111, ST5112	Notebook Tip 11	

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Fujitsu	Stylistic Range – 3400, 3500, ST41 I0, ST41 I0P, ST41 I20, ST41 I20P, ST41 I21, ST5010, ST5010D, ST501 I, ST501 ID, ST5020, ST5020D, ST502 I, ST502 ID, ST5022, ST5022D, ST5030, ST5030D, ST503 I, ST503 ID, ST5032, ST5032D, ST51 I1, ST51 I2 Stylistic LT C-500, Stylistic LT P-600, Tablet ST41xx A/P, Tablet ST501x A/P Amilo M M1420, Amilo M M7400, Amilo Pro V2000D	Notebook Tip 11
Gateway	400SD4, 400VTX, 4012GZ, 4024GZ, 4026GZ, 4028GZ, 405E, 405X, 450ROG, 450SX4, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 600YG2, 600YGR, M305, M500, 3018GZ, 3040GZ, 3520GZ, 3522GZ, 3525GB, 3545GZ, 3550GH, 3550GZ, 3610GZ, 4025GZ, 450RGH, 4520GZ, 4542GP, 6010GZ, 6018GH, 6018GZ, 6020GZ, 6021GH, 6021GZ, 6022GZ, 6023GP, 6510GZ, 6518GZ, 6520GZ, 6525GP, 6531GZ, C-120X, C-140X (Intel Graphic Card), CX200S, CX200X, CX210S, CX210X, CX2608, CX2610, CX2618, CX2619, CX2620, CX2720, CX2724, CX2726, CX2728, E-100M, E-100M G, E-100M SB, M-6801m, M-6802m, M-6815, M-6821b, M210, M250, M250A, M250B, M250E, M250ES, M250G, M250GS, M255-E, M255-E SB, M255-G, M275, M280, M280E-QS, M305CRV, M360, M360A, M360B, M360C, M405, M460, M460A, M460B, M505, ML3706, ML6226b, ML6227b, ML6227q, ML6227v, ML6227z, ML6228, ML6703, MP6954, MP6954h, MP8708, MT3418, MT3705, MT3707, MT6451, MT6704, MT6704h, MT6705, MT6706, MT6707, MT6708, MT6709, MT6709h, MT6711, MT6821, MT6828, MT6828h, MT6830, MT6831, MT6832b, MT6833b, MT6834b, MT6835j, MT6839b, MT6840, MT6840h, MT6841, MT6842b, MX3042, MX3044, MX3044h, MX3210, MX3215, MX3228, MX3230, MX3231, MX3414, MX3416, MX3558, MX3560, MX3560h, MX3562, MX3565h, MX3563h, MX6025, MX6025h, MX6027, MX6027h, MX6028, MX6030, MX6121, MX6123, MX6124, MX6124h, MX6128, MX6131, MX6214, MX6215b, MX6421, MX6422, MX6425, MX6426, MX6427, MX6431, MX6436, MX6437, MX6439, MX6440, MX6441, MX6444, MX6445, MX6446, MX6447, MX6448, MX6450, MX6454, MX6455, MX6625, MX6627, MX6627h, MX6635b, MX6638B, MX6641, MX6650, MX6650h, MX6710, MX6912, MX6920, MX6927, MX6930, MX6931, MX8711, MX8734, MX8738, MX8739, NX100X, NX200S, NX200X, NX250X, NX260X, NX270S, NX500S, NX500X, NX500XL, NX510, NX550X, NX550XL, NX570QS, NX860S, S-7200C, S-7200N, S-7500N, T-6801m, T-6815, T-6815h, T-6816, T-6816h, T-6817c, T-6818c, Solo 1100, Solo 1150, Solo 1200, Solo 1400, Solo 1450, Solo 2150, Solo 2300, Solo 2500, Solo 2550, Solo 3100, Solo 3150, Solo 5150, Solo 5300, Solo 5350, Solo 9100, Solo 9150, Solo 9300, Solo 9300VE, Solo 9500, Solo 9550, Solo Pro 9300-E, Tablet M1200, Tablet M1300	Notebook Tip 14 Notebook Tip 03
Grid	1650, 1660, 1680 1700, 386NX	Notebook Tip 03 Notebook Tip 11
HP	530, Business Tablet TC4200, DV1710us, DV5106TX, DV5155EU, DV6302EA, dv6436nr, L2000, L2005A3, L2005A4, L2005CL, L2005CU, L2005US, L2098XX, L2099XX, Presario V6305NR Pavilion Range – DV1000, DV1001AP, DV1002AP, DV1003AP, DV1004AP, DV1005AP, DV1005EA, DV1006AP, DV1007AP, DV1008AP, DV1009AP, DV1010AP, DV1010CA, DV1010US, DV1012LA, DV1013AP, DV1014AP, DV1014LA, DV1015AP, DV1015LA, DV1016AP, DV1017AP, DV1018AP, DV1019AP, DV1019EA, DV101EAP, DV1020AP, DV1021AP, DV1022AP, DV1023AP, DV1024AP, DV1024LA, DV1025AP, DV1025LA, DV1026AP, DV1027AP, DV1029AP, DV1030AP, DV1031AP, DV1040CA, DV1040US, DV1044LA, DV1045EA, DV1045LA, DV1049CL, DV1049EA, DV1050EA, DV1055EA, DV1060US, DV1064EA, DV1065EA, DV1065US, DV1066EA, DV1067EA, DV1075EA, DV1100, DV1101AP, DV1102AP, DV1103AP, DV1104AP, DV1105AP, DV1105EA, DV1106AP, DV1107AP, DV1107EA, DV1108AP, DV1108EA, DV1109AP, DV1109EA, DV1110AP, DV1110EA, DV1111AP, DV1111EA, DV1112AP, DV1112EA, DV1113AP, DV1115AP, DV1115LA, DV1116AP, DV1117AP, DV1118AP, DV1119AP, DV1120AP, DV1121AP, DV1122AP, DV1123AP, DV1124AP, DV1125AP, DV1125EA, DV1125LA, DV1127AP, DV1128AP, DV1129AP, DV1130AP, DV1130CA, DV1130EA, DV1130US, DV1131AP, DV1131EA, DV1132AP, DV1133AP, DV1133WM, DV1134AP, DV1135AP, DV1135EA, DV1135LA, DV1136AP, DV1136EA, DV1137AP, DV1137EA, DV1138EA, DV1139AP, DV1139EA, DV1140EA, DV1142EA, DV1145EA, DV1150US, DV1152EA, DV1153EA, DV1154EA, DV1155EA, DV1156CL, DV1159EA, DV1160EA, DV1165EA, DV1167EA, DV1168EA, DV1170CA, DV1170EA, DV1170US, DV1175US, DV1180EA, DV1180US, DV1190EA, DV1207US, DV1210US, DV1217US, DV1220EA, DV1220US, DV1224EA, DV1225EA, DV1227US, DV1230EA, DV1240CA, DV1240US, DV1245EA, DV1249EA, DV1250EA, DV1251EA, DV1252EA, DV1253EA, DV1254EA, DV1255EA, DV1258EA, DV1259EA, DV1260EA, DV1262EA, DV1263EA, DV1265EA, DV1266EA, DV1267EA, DV1270EA, DV1272EA, DV1275EA, DV1280EA, DV1281EA, DV1300, DV1301XX MV IUR, DV1302XX MV IUR, DV1310US, DV1311AP, DV1311SE, DV1312AP, DV1313AP, DV1314AP, DV1315AP, DV1315CL, DV1315LA, DV1316AP, DV1317AP, DV1317LA, DV1318AP, DV1319AP, DV1320AP, DV1320BR, DV1320US, DV1321AP, DV1321US, DV1324AP, DV1325AP, DV1325EA, DV1325LA, DV1326AP, DV1326EA, DV1327AP, DV1328AP, DV1329AP, DV1330AP, DV1330BR, DV1330CA, DV1331AP, DV1331EA, DV1331SE, DV1332AP, DV1332EA, DV1333AP, DV1333EA, DV1334AP, DV1335AP, DV1335LA, DV1336AP, DV1338AP, DV1339AP, DV1340AP, DV1340BR, DV1340US, DV1341AP, DV1342AP, DV1343AP, DV1344AP, DV1345AP, DV1345EA, DV1346AP, DV1347AP, DV1348AP, DV1349AP, DV1350AP, DV1350EA, DV1350EA, DV1351AP, DV1351EA, DV1352AP, DV1352EA, DV1353AP, DV1353EA, DV1354AP, DV1354EA, DV1355AP, DV1355EA, DV1356AP, DV1356EA, DV1357AP, DV1358AP, DV1358EA, DV1359AP, DV1359EA, DV1360AP, DV1361AP, DV1362AP, DV1362EA, DV1362TU, DV1363AP, DV1363EA, DV1364AP, DV1365AP, DV1365EA, DV1366AP, DV1366EA, DV1367TU, DV1368TU, DV1369TU, DV1370TU, DV1371TU, DV1372TU, DV1373TU, DV1374TU, DV1375EA, DV1375EA, DV1375TU, DV1376TU, DV1379TU, DV1380TU, DV1381TU, DV1382TU, DV1383TU, DV1384TU, DV1385TU, DV1386TU, DV1387TU, DV1388TU, DV1389TU, DV1390TU, DV1391TU, DV1392TU, DV1393TU, DV1394TU, DV1395TU, DV1396TU, DV1399XX MV IUR, DV1410US, DV1411SE, DV1420CA, DV1420US, DV1427US, DV1430US, DV1432US, DV1439CA, DV1439US, DV1440CA, DV1440US, DV1510US, DV1515CL, DV1519US, DV1520CA, DV1520US, DV1530CA, DV1530US, DV1532US, DV1550SE, DV1580SE, DV1600, DV1610US, DV1620US, DV1624NR, DV1629US, DV1648US, DV1650US, DV1656US, DV1658US, DV1659US, DV1660SE, DV1670US, DV1680CA, DV1680US, DV1688US, DV1708NR, DV1738OD	Notebook Tip 02

Laptops / Notebooks

<p>HP</p>	<p>Pavilion Range – DV2000, DV2000Z, DV2002TU, DV2015NR, DV2017TU, DV2020CA, DV2020US, DV2025NR, DV2029EA, DV2029TU, DV2035US, DV2036EA, DV2036TU, DV2037US, DV2040CA, DV2040US, DV2045EA, DV2045TU, DV2047CL, DV2050US, DV2054EA, DV2104EA, DV2104EU, DV2110RS, DV2120US, DV2125NR, DV2130US, DV2201CA, DV2205EA, DV2210US, DV2214US, DV2220US, DV2221US, DV2225NR, DV2275EA, DV2310US, DV2315NR, DV2415NR, DV2415US, DV2501xx, DV2502TU, DV2505TU, DV2506xx, DV2506xx, DV2508TU, DV2509TU, DV2510TU, DV2511TU, DV2512TU, DV2513TU, DV2514TU, DV2515EA, DV2515TU, DV2516TU, DV2517TU, DV2518TU, DV2519EA, DV2519TU, DV2520EA, DV2520TU, DV2521EA, DV2521TU, DV2525EA, DV2528EA, DV2529EA, DV2530EA, DV2550SE, DV2554EA, DV2555EA, DV2560EA, DV4000xx MV IUR, DV4001AP, DV4001EA, DV4001xx MV IUR, DV4002AP, DV4003AP, DV4004AP, DV4004xx MV IUR, DV4005AP, DV4005US, DV4005xx MV IUR, DV4006AP, DV4006xx MV IUR, DV4007AP, DV4007xx MV IUR, DV4008AP, DV4009AP, DV4010AP, DV4011AP, DV4012AP, DV4013AP, DV4014AP, DV4014EA, DV4015AP, DV4015CL, DV4015EA, DV4016AP, DV4016EA, DV4017AP, DV4017EA, DV4018AP, DV4018CL, DV4018EA, DV4019AP, DV4019EA, DV4020AP, DV4020EA, DV4020US, DV4021AP, DV4021EA, DV4022AP, DV4022EA, DV4023AP, DV4023EA, DV4024AP, DV4024EA, DV4025EA, DV4026AP, DV4027EA, DV4029EA, DV4030CA, DV4030EA, DV4030US, DV4031EA, DV4037EA, DV4040CA, DV4040EA, DV4040US, DV4043EA, DV4045EA, DV4046EA, DV4049EA, DV4050EA, DV4051EA, DV4052EA, DV4054EA, DV4056EA, DV4057EA, DV4060EA, DV4070EA, DV4073EA, DV4075EA, DV4078EA, DV4080EA, DV4085EA, DV4086EA, DV4100, DV4103EA, DV4103EA, DV4108EA, DV4109EA, DV4110EA, DV4113EA, DV4115EA, DV4117AP, DV4122EA, DV4124EA, DV4125EA, DV4125US, DV4126AP, DV4126EA, DV4128EA, DV4129EA, DV4130EA, DV4130US, DV4131EA, DV4134EA, DV4135EA, DV4136EA, DV4137EA, DV4138EA, DV4139EA, DV4140EA, DV4141EA, DV4142EA, DV4143EA, DV4144EA, DV4145EA, DV4146EA, DV4148EA, DV4149EA, DV4150EA, DV4150US, DV4151EA, DV4152EA, DV4153EA, DV4154EA, DV4155EA, DV4156EA, DV4157EA, DV4158EA, DV4159EA, DV4160EA, DV4161EA, DV4162EA, DV4163EA, DV4164EA, DV4165CL, DV4165EA, DV4170US, DV4174EA, DV4176EA, DV4178EA, DV4182EA, DV4199EA, DV4201TU, DV4201TX, DV4202TU, DV4202TX, DV4203EA, DV4203TU, DV4203TX, DV4204TU, DV4204TX, DV4205TX, DV4206TX, DV4207EA, DV4207TU, DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX, DV4213TX, DV4214TX, DV4215TX, DV4216TX, DV4217CL, DV4217TX, DV4218TX, DV4219TX, DV4220TX, DV4221TX, DV4222TX, DV4223CL, DV4223EA, DV4223TX, DV4224TX, DV4225EA, DV4225NR, DV4225TX, DV4226EA, DV4227EA, DV4230US, DV4232EA, DV4234EA, DV4235EA, DV4236EA, DV4241EA, DV4243EA, DV4245EA, DV4246EA, DV4250EA, DV4250US, DV4251EA, DV4253EA, DV4253US, DV4254EA, DV4257US, DV4261EA, DV4264EA, DV4266EA, DV4268EA, DV4269EA, DV4270CA, DV4270EA, DV4270US, DV4271EA, DV4272EA, DV4272US, DV4273EA, DV4275EA, DV4275NR, DV4276EA, DV4277EA, DV4280EA, DV4282EA, DV4283EA, DV4284EA, DV4285EA, DV4287EA, DV4288EA, DV4289EA, DV4290EA, DV4291EA, DV4294EA, DV4295EA, DV4296EA, DV4305US, DV4307CA, DV4307CL, DV4308WM, DV4310US, DV4320US, DV4330CA, DV4330US, DV4335US, DV4340CA, DV4340US, DV4401RS, DV4405NR, DV4419US, DV4420CA, DV4420US, DV4935WM, DV5000, DV5000T, DV5020US, DV5029EA, DV5030US, DV5035NR, DV5040US, DV5100, DV5101TU, DV5101TX, DV5102TU, DV5102TX, DV5103TX, DV5104TU, DV5104TX, DV5105TX, DV5107TX, DV5108TX, DV5109TX, DV5110EU, DV5110TX, DV5110US, DV5112TX, DV5113TX, DV5114TX, DV5115NR, DV5115TX, DV5116NR, DV5116TX, DV5117CA, DV5117TX, DV5118TX, DV5120EA, DV5120LA, DV5120TX, DV5120US, DV5121EA, DV5122EA, DV5123EA, DV5123TX, DV5124TX, DV5125EU, DV5125TX, DV5126EA, DV5126TX, DV5127EA, DV5127TX, DV5128EA, DV5128TX, DV5129TX, DV5129US, DV5130EA, DV5130TX, DV5130US, DV5131TX, DV5133EA, DV5134EA, DV5135NR, DV5137EA, DV5139US, DV5140EA, DV5140US, DV5142EA, DV5143EA, DV5144EA, DV5145EA, DV5147EA, DV5148EA, DV5149EA, DV5150EA, DV5150US, DV5156EA, DV5157EA, DV5158EA, DV5159EA, DV5160EA, DV5161EA, DV5162EA, DV5164EA, DV5165EA, DV5166EA, DV5170US, DV5173EA, DV5175EA, DV5176EA, DV5177EA, DV5178EA, DV5178US, DV5179EA, DV5180EA, DV5184EA, DV5188EA, DV5190EA, DV5191EA, DV5192EA, DV5193EA, DV5194EA, DV5195EA, DV5196EA, DV5196XX, DV5197EA, DV5197XX, DV5200, DV5200TU, DV5200TX, DV5201EU, DV5201TU, DV5201TX, DV5202TU, DV5202TX, DV5203EA, DV5203TU, DV5203TX, DV5204EA, DV5204TU, DV5204TX, DV5205EA, DV5205TX, DV5206TU, DV5206TX, DV5207TX, DV5208TX, DV5209TX, DV5210CA, DV5210TX, DV5210US, DV5211EA, DV5211TX, DV5212EA, DV5212TX, DV5213TX, DV5214TX, DV5215CA, DV5215TX, DV5215US, DV5216TX, DV5217TX, DV5218EA, DV5218NR, DV5218TX, DV5219TX, DV5220CA, DV5220LA, DV5220TX, DV5220US, DV5221TX, DV5222NR, DV5222TX, DV5223OM, DV5223TX, DV5224EA, DV5224NR, DV5224TX, DV5225EA, DV5225TX, DV5226CA, DV5226EU, DV5226TX, DV5227TX, DV5228TX, DV5229OM, DV5229TX, DV5230CA, DV5230TX, DV5230US, DV5231TX, DV5232EU, DV5232TX, DV5233EA, DV5233TX, DV5234EA, DV5234US, DV5235CA, DV5235EA, DV5235TX, DV5236EA, DV5236EU, DV5236OM, DV5236TX, DV5237CL, DV5237EA, DV5237TX, DV5240CA, DV5240EA, DV5241EA, DV5242EA, DV5243EA, DV5244EA, DV5244EU, DV5245EA, DV5247EA, DV5248EA, DV5249EA, DV5250CA, DV5250EA, DV5250US, DV5261EA, DV5264EA, DV5266EA, DV5267EA, DV5274EA, DV5275EA, DV5276EA, DV5276EU, DV5277EA, DV5279EU, DV5280EA, DV5282EA, DV5284EA, DV5285EA, DV5287EA, DV5289EA, DV5292EA, DV5293EA, DV5294EA, DV5295EA, DV5296EA, DV5298EA,</p>
------------------	--

Notebook Tip 02

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
HP	Pavilion Range – 2105US, 3101, 4101, 4103, 4105, 5159, N3110, N3150, N3190, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3310, N3330, N3350, N3370, N3380, N3390, N3402, N3410, N3438, N3478, N3490, N5000 BTCO, N5124, N5125, N5130, N5135, N5140, N5150, N5159, N5170, N5190, N5195, N5210, N5221, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5331, N5340, N5341, N5350, N5351, N5361, N5371, N5381, N5390, N5401, N5402, N5402L, N5412, N5415, N5420, N5421, N5421L, N5422, N5422L, N5425, N5430, N5431L, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5451, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511L, N5584, N6190, N6195, N6300 BTO, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6402, N6403, N6404, N6490, XF125, XF145, XF235, XF255, XF315, XF325, XF328, XF335, XH136, XH156, XH176, XH215, XH216, XH226, XH355, XH365, XH395, XH455, XH485, XH525, XH535, XH545, XH555, XH575, XH625, XH675, XT115, XT118, XT125, XT128, XT155, XT188, XT236, XT276, XT345, XT375, XT395, XT412, XT5377, XT545, XT555, XT565, XT575, XT585, XT595, XU/ZU BTCO, XU155, XZ133, XZ148, XZ163, XZ168, XZ185, XZ275, XZ295, XZ335, XZ355, ZE1000, ZE1110, ZE1115, ZE1145, ZE1201, ZE1202, ZE1210, ZE1230, ZE1250, ZE1260, ZE4101, ZE4102, ZE4103, ZE4105, ZE4111, ZE4115, ZE4120, ZE4123, ZE4125, ZE4130, ZE4133, ZE4140, ZE4145, ZE4200, ZE4201, ZE4202, ZE4204, ZE4206, ZE4207, ZE4208, ZE4209, ZE4210, ZE4211, ZE4214, ZE4218, ZE4219, ZE4220, ZE4221, ZE4222, ZE4224, ZE4228, ZE4229, ZE4230, ZE4231, ZE4232, ZE4234, ZE4236, ZE4239, ZE4240, ZE4241, ZE4251, ZE4258, ZE4261, ZE4268, ZE4271, ZE4274, ZE4278, ZE4281, ZE4282, ZE4284, ZE4288, ZE4292, ZE4294, ZE4298, ZE4301, ZE4305, ZE4307, ZE4308, ZE4310, ZE4311, ZE4312, ZE4313, ZE4314, ZE4315, ZE4315US, ZE4316, ZE4317, ZE4318, ZE4319, ZE4320, ZE4321, ZE4323, ZE4325, ZE4325US, ZE4330, ZE4332, ZE4333, ZE4334, ZE4335, ZE4336, ZE4337, ZE4338, ZE4339, ZE4340, ZE4341, ZE4342, ZE4343, ZE4344, ZE4345, ZE4346, ZE4347, ZE4348, ZE4349, ZE4350, ZE4351, ZE4352, ZE4353, ZE4354, ZE4355, ZE4356, ZE4357, ZE4358, ZE4359, ZE4360, ZE4365, ZE4367, ZE4375, ZE4384, ZE4385, ZE4386, ZE5715CA, ZT1000-IB BTCO, ZT1114, ZT1120, ZT1121, ZT1121S, ZT1122, ZT1122S, ZT1125, ZT1130, ZT1131, ZT1131S, ZT1132, ZT1132S, ZT1135, ZT1141, ZT1142, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1172, ZT1175, ZT1180, ZT1181, ZT1182, ZT1185, ZT1190, ZT1192, ZT1201, ZT1201S, ZT1210, ZT1211, ZT1213, ZT1230, ZT1231S, ZT1233, ZT1235, ZT1243, ZT1250, ZT1260, ZT1261, ZT1270, ZT1271, ZT1290, ZT1331, ZU1155, ZU1175, ZU175 Satellite A205-S4607	Notebook Tip 03
IBM	ThinkPad X60, ThinkPad X60 Tablet, ThinkPad X60s, ThinkPad Z61e, ThinkPad Z61m, ThinkPad Z61t	Notebook Tip 31
IDP	87, 910T	Notebook Tip 03
Inca	Legend 60	Notebook Tip 03
Intergraph	6200AT	Notebook Tip 03
Inteva	TS30H, TS30T	Notebook Tip 03
Iona	1100	Notebook Tip 03
Jetta	JetBook 9100	Notebook Tip 03
Kapok	6100, 6300, 6400, 7200, 7600, 7800	Notebook Tip 03
KDS	Valiant Range – 5000, 5340AS, 5350AS, 6370, 6370iPT, 6380iPTD, 6480iPTD, 6481iPTD, 6530, 671DP, 671XH	Notebook Tip 03
KTX	1000	Notebook Tip 12
Lap-Note	98, Z200, Z300	Notebook Tip 03
Lenovo	3000 C200, 3000 C C100, 3000 N N100 (Intel Graphic card), 3000 V V100, ThinkPad T60 (Intel Graphic card), ThinkPad X60, ThinkPad X60 Tablet, ThinkPad X60s, ThinkPad X61 Tablet, ThinkPad X61s, ThinkPad Z61e, ThinkPad Z61m, ThinkPad Z61t	Notebook Tip 31
Magitronic	550, 800, 820T, 862, MM86, P86	Notebook Tip 03
Maximus	Green 759	Notebook Tip 03
Medion	MD9326	Notebook Tip 03
MegalImage	MegaBook 770, MegaBook 880	Notebook Tip 11
	Apollo, MegaBook 911CD	Notebook Tip 12
Micon	6200D	Notebook Tip 03
Micro Express	NP8500, NP92DX4	Notebook Tip 03
Micro International	6200, 6200D	Notebook Tip 03
Micro Quest	P79	Notebook Tip 03
MicroFlex	FlexNote	Notebook Tip 03
Micron	TransPort Trek2, TransPort Trek2 233, TransPort Trek2 266, TransPort Trek2 300DVD	Notebook Tip 03
MicroStar	6200D	Notebook Tip 03
Midwest Micro	TS30SI, TS30ST	Notebook Tip 03
Mitac	4023	Notebook Tip 06
Mobile Computing	@Book 1100, @Book 900	Notebook Tip 03
MPC	M700, TouchNote 700	Notebook Tip 03
Multimedia Notebook	6200AT, 6600, 86, 862, 98	Notebook Tip 03

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
NCR	3140, 3141	Notebook Tip 06
NEC	<p>LaVie C Range – LC500/4D, LC700/4D, LC700/6D, LC700/7D, LC700/8D, LC900/4D, LC900/7D, LC900/8E, LC950/4D, PC-LC3001A, PC-LC3002D, PC-LC5001D, PC-LC5002D, PC-LC5003D, PC-LC5004D, PC-LC5005D, PC-LC5503DW, PC-LC7001D, PC-LC7003D, PC-LC7004D, PC-LC7005D, PC-LC9001D, PC-LC9002D, PC-LC9003E, PC-LC9004D, PC-LC9005D, PC-LC9503E, PC-LC9504E</p> <p>LaVie F Range – LF550/4D, LF550/5D, LF750/6D, LF750/7D, LF750/8D, PC-LF5504D, PC-LF5505D, PC-LF7507D</p> <p>LaVie G Range – PC-LG10JLFEA, PC-LG10JLFEB, PC-LG10JLFJA, PC-LG10JLFB, PC-LG10JSFEA, PC-LG10NRXEA, PC-LG10NRXJA, PC-LG10RRXEB, PC-LG10RRXJB, PC-LG11NRXEB, PC-LG11NRXJB, PC-LG14NFXEC, PC-LG14NRXEC, PC-LG14NRXJC, PC-LG14SSFEB, PC-LG14SSFJB, PC-LG14SSGEB, PC-LG14SSGJB, PC-LG15HLXEC, PC-LG15HLXJC, PC-LG15SEFEC, PC-LG15SEFJC, PC-LG15SSFEC, PC-LG15SSFJC, PC-LG15SSGEC, PC-LG15SSGJC, PC-LG16HEVED, PC-LG16HEVJD, PC-LG16HLFED, PC-LG16HLFJD, PC-LG16HLVED, PC-LG16HLVJD, PC-LG16NFXED, PC-LG16NFXED, PC-LG16NRXED, PC-LG16NRXJD, PC-LG16SLFED, PC-LG16SLFJD, PC-LG16SLVED, PC-LG16SLVJD, PC-LG16SSUJB, PC-LG18SEFEC, PC-LG18SEFJC, PC-LG18SEVED, PC-LG18SEVJD, PC-LG18SSFED, PC-LG18SSFJD, PC-LG18SSGED, PC-LG18SSGJD, PC-LG18SSUEC, PC-LG18SSUJB, PC-LG18SSUJC, PC-LG19NRXEC, PC-LG19NRXJC, PC-LG20NRXED, PC-LG20NRXJD, PC-LG20SEGEC, PC-LG20SEGED, PC-LG20SEGJD, PC-LG20SSUEC, PC-LG20SSUED, PC-LG20SSUJC, PC-LG20SSUJD, PC-LG90RRXEA, PC-LG90RRXJA</p> <p>LaVie J Range – LC500/4D, LC500/5D, LC700/4D, LC700/5D, LC700/6D, LC900/4D, LC900/5D, LC950/4E, LJ500/4D, LJ500/5A, LJ500/6A, LJ700/4E, LJ700/4F, LJ700/5E, LJ700/7E, LL300/4F, LL350/8D, LL350/9D, LL350/AD, LL350/BD, LL500/9D, LL500/AD, LL530/7A, LL550/7D, LL550/BD, LL570/8D, LL700/5D, LL700/6D, LL700/7D, LL730/5D, LL750/4DW, LL750/7D, LL750/8D, LL750/9D, LL750/AD, LL750/BD, LL770/6DT, LL770/7DT, LL770/8DT, LL770/AD, LL770/BD, LL7700/9DT, LL850/BD, LL900/5D, LL900/6D, LL900/7D, LL900/8D, LL900/9D, LL900/AD, LL900/BD, LL930/5D, LL950/6D, LL950/7D, LL950/8D, LL970/9D, LS500/9DT, LS500/AD, LS700/8D, LS700/9D, LS700/AD, LS830/9D, LS830/AD, LS900/8E, LT300/5D, LT500/4D, LT500/5D, LT500/6D, LT700/4D</p> <p>LaVie L Range – LL300/4F, LL500/4D, LL500/5D, LL500/6D, LL530/7A, LL550/4D, LL550/5D, LL550/6D, LL550/7D, LL700/4D, LL700/6D, LL700/7D, LL750/4D, LL750/7D, LL770/6DT, LL770/7DT, LL900/6D, LL900/7D, LL950/6D, PC-LL3001A, PC-LL3004F, PC-LL5001D, PC-LL5002D, PC-LL5003D, PC-LL5004D, PC-LL5005D, PC-LL5503D, PC-LL5504D, PC-LL5505D, PC-LL7001D, PC-LL7002D, PC-LL7003D, PC-LL7004D, PC-LL7005D, PC-LL7305D, PC-LL7502D, PC-LL7503D, PC-LL7504DW, PC-LL9001D, PC-LL9005D, PC-LL9305D, PC-LL9507D</p> <p>LaVie M Range – LE300/6A, LE500/6D, LE500/7D, LM500/4E, LM500/5D, LM500/7D, LM500/8D, LM550/5E, LM700/7E, LR300/8D, LR500/9D, LR500/AD, LR500/BD, LR700/8E, LR700/9E, LT700/AD, LT900/AD, LT900/BD</p> <p>LaVie ME LE500/7D, LaVie N LN300/BD, LaVie N LN390/BD, LaVie N LN500/6D, LaVie N LN500/7D, LaVie N LN570/7DT, LaVie Pro PC-LH3002A, LaVie Pro PC-LH3003F, LaVie Pro PC-LH7002D, LaVie Pro PC-LH7003E, LaVie RX LR5000/BD</p> <p>LaVie T Range – LN300/9DB, LN300/9DW, LN300/AD1, LN300/AD2, LN300/BD, LN390/BD, LN500/4D, LN500/6D, LN500/7D, LN500/9DB, LN500/9DW, LN500/AD1, LN500/AD2, LN570/7DT, LT500/4D, LT500/6D, LT700/4D, PC-LT3005D, PC-LT5004D, PC-LT5005D, PC-LT7004D</p> <p>Pocket Gear MC/PG5000, Pocket Gear MC/PG7000, Ready 220T, Ready 230T, Ready 330T, Ready 340T, Ready 360T, Ready 440T</p> <p>Versa Range – 2400, 2500, 2500CD, 2505, 2530, 4000, 4000C, 4000D, 4000Hs, 4050C, 4050D, 4050H, 4080H, 4200, 4230, 500, 5000, 5060, 5060X, 5080, 5080X, 550D, C140, C150, C160, E120, E600, FM320, FM500, FP520, FS800, IGO3000, IGO5000, IGO6000, L320, M300, M320, M3210, M500, P440, P520, P600, P700, S800, T400, T400S820, VersaNote, VX</p> <p>Versa Pro Range – VY13M/AF-T, VY13M/DF-R, VY13M/EF-R, VY13M/EX-R, VY13M/RF-R, VY13M/RX-R, VY16F/EF-R, VY16F/EX-R, VY16F/RF-R, VY16F/RX-R, VY17F/AF-T, VY17F/AG-T, VY17F/DF-R, VY17F/DG-R, VY18F/RF-R, VY20F/AE-T, VY20F/AF-T, VY20F/AG-T, VY20F/DF-R, VY20F/DG-R</p> <p>Versa Pro J Range – VJ13M/AF-T, VJ13M/DF-R, VJ13M/RF-R, VJ13M/RX-R, VJ16F/RF-R, VJ16F/RX-R, VJ17F/AF-T, VJ17F/AG-T, VJ17F/DF-R, VJ17F/DG-R, VJ18F/RF-R, VJ20F/AE-T, VJ20F/AF-T, VJ20F/AG-T, VJ20F/DF-R, VJ20F/DG-R</p> <p>VersaPro NX LW23C/52, VersaPro NX LW23D, VersaPro NX LW26H, VersaPro NX LW30H, VersaPro NX LW33H</p>	Notebook Tip 03
Nimantics	6200T, P79, SL86, Orion 10XL, Orion HSI66M	Notebook Tip 03
Northgate	NB86	Notebook Tip 03
Nova	NP8100, NP8320, MultiMedia 86	Notebook Tip 03
Olivetti	Xtreme, Echos 1200L, Echos 910, Echos P100, Echos P100C, Echos P100D, Echos P100E, Echos P120, Echos P120E, Echos P133S, Echos P1400C, Echos P90, Echos Pro, Echos Pro 150X, Echos Pro P133	Notebook Tip 03
Olympia	386SX, LT386SX	Notebook Tip 03
Outbound	2000, 2030, 2030A	Notebook Tip 03

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Panasonic	Toughbook Range – CF-01, CF-11, CF-17, CF-170, CF-25, CF-27, CF-270, CF-28, CF-33, CF-34, CF-35, CF-37, CF-370, CF-380, CF-41, CF-45, CF-47, CF-61, CF-62, CF-63, CF-71, CF-M34, CF-V25, CF-V41	Notebook Tip 11
	Toughbook Range – CF-V21, CF-V21P	Notebook Tip 12
Patriot	800, 8000, 860C, 8890, 9000 C86, FT6000A	Notebook Tip 03
Philips	NB470, NB570, TravelMate 570	Notebook Tip 03
Pionex	N30W, TS30i	Notebook Tip 03
Prostar	7200, 86	Notebook Tip 03
Quantex	1511-I, I-1410, N30W, T-1401, T-1410, T-1411, TS30H, TS30H-1331, TS30I, TS30I3, TS30T, W-1400, W-1500, W-1500 700, W-1511	Notebook Tip 03
Sager	6200, 6200D, 7200, 8549 D20, 86, 862, 87, 8700, 98, NB8600, NB8700, NP8100, NP8300, NP8500, NP8550, NP8600, NP8620, NP8623, NP8680, NP8700, P86	Notebook Tip 03
Samsung	NoteMaster 486C/25	Notebook Tip 06
	Sens 700, Sens 800	Notebook Tip 11
	Sens 500, Sens 810, SensPro 500, SensPro 505, SensPro 520, SensPro 521, SensPro 525	Notebook Tip 12
Sceptre	N30W, NB30B2, TS30H, TS30W, SoundX S, SoundX S5200T, SoundX S5500T,	Notebook Tip 03
Sharp	PC-3010, PC-3020, PC-3050, PC-3060, PC-3150	Notebook Tip 03
Smart-Tec	NX-6000, NX-6600	Notebook Tip 03
Sony	Picturebook C1X	Notebook Tip 11
	VAIO Range – B55T, CIMHP, CIMT, CIMTI, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, PCG-C1MAH, PCG-C1MEL, PCG-C1MR/BP, PCG-C1MRX, PCG-C1MSX, PCG-C1MTL, PCG-C1MZX, PCG-GR3F/BP, PCG-GR3N/BP, PCG-GR5E/BP, PCG-GR5F/BP, PCG-GR5N/BP, PCG-GR7/K, PCG-GR7E, PCG-GR7F, PCG-GR9, PCG-GR9/K, PCG-GR90E, PCG-GR90E/K, PCG-GR90F, PCG-GR90F/P, PCG-GR9E, PCG-GR9F/P, PCG-GT1, PCG-GT3/K, PCG-SR1/BP, PCG-SR19GKRT, PCG-SR1C/BP, PCG-SR1G/BP, PCG-SR1M, PCG-SR1M/BP, PCG-SR9/K, PCG-SR9C/BK, PCG-SR9C/K, PCG-SR9C/P, PCG-SR9G/K, PCG-SR9M/G, PCG-SR9M/K, PCG-SRX3, PCG-SRX3/BD, PCG-SRX3E, PCG-SRX3E/BD, PCG-SRX3F/BD, PCG-SRX3S/BD, PCG-SRX55H, PCG-SRX55L, PCG-SRX55TH, PCG-SRX55TL, PCG-SRX7, PCG-SRX7E/P, PCG-SRX7F/P, PCG-SRX7F/PB, PCG-SRX7S/P, PCG-SRX7S/PB, PCG-SRX87, PCG-TR1, PCG-TR1/B, PCG-TR1/P, PCG-TR1L, PCG-TR1MP, PCG-TR1S, PCG-TR2, PCG-TR2/B, PCG-TR2/P, PCG-TR2E, PCG-TR2L, PCG-TR2MP, PCG-TR2S, PCG-TR3, PCG-TR3/B, PCG-TR3/P, PCG-TR3/S, PCG-TR3/SP, PCG-TR3AP3, PCG-TR3E/B, PCG-TR3S, PCG-TR5AP, PCG-TR5B, PCG-TR5EB, PCG-TR5L, PCG-TR5MP, PCG-TR5PS, PCG-TR5S, PCG-UI, PCG-UI01, PCG-UI01/P, PCG-U3, PCG-U3/P, PCG-V505/B, PCG-V505AK, PCG-V505E/B, PCG-V505ECP14, PCG-V505F/B, PCG-V505G/B, PCG-V505GL, PCG-V505GP, PCG-V505GSP, PCG-V505L, PCG-V505MLP, PCG-V505MNP, PCG-V505MNSP, PCG-V505MP, PCG-V505MSP, PCG-V505MZL, PCG-V505P, PCG-V505R/PB, PCG-V505S/PB, PCG-V505SP, PCG-V505TI, PCG-V505TI/P, PCG-V505T2, PCG-V505T2/P, PCG-V505T3, PCG-V505T3/P, PCG-V505T4, PCG-V505T4/P, PCG-V505V/P, PCG-V505VZ/P, PCG-V505W/P, PCG-VX7/BD, PCG-VX9/P, PCG-X505/P, PCG-X505/SP, PCG-X505CP, PCG-Z1/P, PCG-Z1G/P, PCG-Z1LP, PCG-Z1MP, PCG-Z1R/P, PCG-Z1RGP, PCG-Z1RLP, PCG-Z1RT/P, PCG-Z1T/P, PCG-Z1V/P, PCG-Z1VE, PCG-Z1VGP, PCG-Z1VJP, PCG-Z1VLP, PCG-Z1VT/P, PCG-Z1VXZLP, PCG-Z1X/P, PCG-Z1XE/B, PCG-Z1XGP, PCG-Z1XJP, PCG-Z1XLP, PCG-Z1XMP, PCG-Z1XSP, PCG-SR19GT, S150, S150P, S18GP, S26TP, S28TP, S36GP, S36TP, SR1, SR11K, SR17, SR17K, SR19G, SR1K, SR21, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T17TP, T26SP, T37GP, T37SP, TR1, TR1A, TR1AP, TR2, TR2A, TR2AP1, TR2AP3, TR3, TR3A, TR3AP1, TR3AP2, TR5GP, V505A, V505AC, V505AX, V505AXP, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P2, V505DC1P7, V505DC1PC, V505DC1PF, V505DC21, V505DC2P1, V505DX, V505DXP, V505EC, V505EC29, V505ECP1, V505ECP29, V505ECP8, V505EX, V505EXP, V505GR, V505MP, V505P, VGN-B100B, VGN-B100B01, VGN-B100B02, VGN-B100B03, VGN-B100B04, VGN-B100B07, VGN-B100B08, VGN-B100B09, VGN-B100B28, VGN-B100GP, VGN-B1VP, VGN-B1XP, VGN-B3VP, VGN-B3XP, VGN-B55C, VGN-B55G, VGN-B55L, VGN-B55S, VGN-B66GP, VGN-B66SP, VGN-B77GP, VGN-B77SP, VGN-B88C, VGN-B88GP, VGN-B88L, VGN-B90PS, VGN-B90PSY1, VGN-B90PSY2, VGN-B90PSY3, VGN-B90PSY4, VGN-B90PSY5, VGN-B90PSY6, VGN-B90PSY7, VGN-B90PSY8, VGN-B90PSYA, VGN-B90PSYB, VGN-B99C, VGN-B99GP, VGN-G11VN/T, VGN-G11XN/B, VGN-G21XP/B, VGN-S16GP, VGN-S16LP, VGN-S16SP, VGN-S170, VGN-S170P6, VGN-S18GP, VGN-S18LP, VGN-S18SP, VGN-S1HP, VGN-S1VP, VGN-S1XP, VGN-S25C, VGN-S260, VGN-S260P, VGN-S26C, VGN-S26GP, VGN-S26LP, VGN-S26SP, VGN-S270, VGN-S270B, VGN-S270B13, VGN-S270P, VGN-S27C, VGN-S28C/P, VGN-S28GP, VGN-S28LP, VGN-S28SP, VGN-S2HP, VGN-S2HRP, VGN-S2VP, VGN-S2XP, VGN-S2XRP, VGN-S360, VGN-S360P, VGN-S36C/B, VGN-S36C/S, VGN-S36GP/S, VGN-S36LP/S, VGN-S36SP, VGN-S38CP/B, VGN-S50B, VGN-S51B, VGN-S52B/S, VGN-S62PS/S, VGN-S62PSY, VGN-S62PSY1, VGN-S62PSY2, VGN-S62PSY3, VGN-S62PSY4, VGN-S62S/S, VGN-S70B, VGN-S71PB, VGN-S90PS, VGN-S90PSY, VGN-S90PSY1, VGN-S90PSY2, VGN-S90PSY3, VGN-S90PSY4, VGN-S90PSY5, VGN-S90PSY6, VGN-S90S, VGN-S91PS, VGN-S91PSY, VGN-S91PSY1, VGN-S91PSY2, VGN-S91PSY3, VGN-S91PSY4, VGN-S91PSY5, VGN-S91PSY6, VGN-S91S	

Laptops / Notebooks

Sony

VAIO Range –
 705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 81, 812, 818, 838, A17GP, A19GP, A29GP, A29TP, C1XW, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, F709K, F801, F801A, F807, F807K, F808K, F809K, FR-55G, FR-55G/B, FR-55J, FR-55J/B, FR-55R/P, FR-77G/B, FR-77J/B, FR102, FR105, FR130, FR700H, FX101, FX103, FX105K, FX108K, FX109K, FX120, FX140, FX150, FX170, FX190, FX200, FX201, FX203, FX203K, FX205K, FX209K, FX220K, FX270, FX301, FX401, FX405, FX501, FX502, FX505, FX601, FX602, FX604, FX605, FX701, FX702, FX705, FX770K, FX800, FX801, FX802, FX804, FX805, FX880K, FX902P, FX905P, FXA32, FXA33, FXA36, FXA63, GRS100, GRS150, GRS515M, GRS515R, GRS515SP, GRS5614MP, GRS700, GRS700K15, GRX316SP, GRX3P, GRX416SP, GRX500, GRX516SP, GRX520, GRX520/B, GRX550, GRX560, GRX570, GRX580K, GRX590, GRX5P, GRX600, GRX650, GRX670, GRX690, GRX700, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PCG-705, PCG-705/S, PCG-707, PCG-713, PCG-713/32, PCG-715, PCG-719, PCG-719/64, PCG-721, PCG-723, PCG-723/BP, PCG-726, PCG-729, PCG-731, PCG-733, PCG-733/A, PCG-733/A3G, PCG-737, PCG-737/A4G, PCG-766/BP, PCG-767, PCG-777/BP, PCG-803, PCG-808, PCG-861/BP, PCG-862, PCG-864, PCG-868, PCG-881/BP, PCG-883, PCG-883/BP, PCG-885, PCG-887, PCG-887/BP, PCG-887/BP2, PCG-888, PCG-F14/BP, PCG-F16/BP, PCG-F20/BP2, PCG-F23/BP, PCG-F23/BP2, PCG-F26/BP, PCG-F26/BP2, PCG-F670T, PCG-F70/BP, PCG-F70A/BP, PCG-F75/BP, PCG-F76/BP, PCG-F79/BPK, PCG-FR33, PCG-FR33/B, PCG-FR55B, PCG-FR55E, PCG-FR55E/B, PCG-FR55G, PCG-FR55G/B, PCG-FR55J, PCG-FR55J/B, PCG-FR55R/P, PCG-FR700, PCG-FR700H, PCG-FR700S, PCG-FR720, PCG-FR720L, PCG-FR720S, PCG-FR77E/B, PCG-FR77G/B, PCG-FR77J/B, PCG-FR820L, PCG-FR820S, PCG-FR825P, PCG-FR825SP, PCG-FRV25, PCG-FX11/BP, PCG-FX11G/BP, PCG-FX11J, PCG-FX11S/BP, PCG-FX11V, PCG-FX11VA, PCG-FX240, PCG-FX240K, PCG-FX33G/BP, PCG-FX33S/BP, PCG-FX33V/BP, PCG-FX390, PCG-FX390K, PCG-FX390P, PCG-FX50G/K, PCG-FX55/BP, PCG-FX55A/BP, PCG-FX55G/BP, PCG-FX55J/B, PCG-FX55S/BP, PCG-FX55V/BP, PCG-FX55Z/BP, PCG-FX55ZA, PCG-FX60G/K, PCG-FX77/BP, PCG-FX770TK, PCG-FX77G/BP, PCG-FX77S/BP, PCG-FX77V/BP, PCG-FX77Z, PCG-FX77Z/BP, PCG-FX800, PCG-FX880K, PCG-FX90/BPK, PCG-FX900, PCG-FX900H, PCG-FX90G/K, PCG-FX950, PCG-FX950H, PCG-FX990, PCG-FX99V/BP, PCG-FXA10H, PCG-FXA10H, PCG-GRS50/B, PCG-GRS500, PCG-GRS500/P, PCG-GRS52V/P, PCG-GRS55/B, PCG-GRS70/P, PCG-GRS72V/P, PCG-GRS900, PCG-GRS900/P, PCG-GRX102/P, PCG-GRX1P, PCG-GRX3HP, PCG-GRX3LP, PCG-GRX51/BP, PCG-GRX52G/B, PCG-GRX5LP, PCG-GRX5P, PCG-GRX71, PCG-GRX72/P, PCG-GRX81G/P, PCG-GRX90/P, PCG-GRX91G/P, PCG-GRX92G/P, PCG-NV55/BP, PCG-NV55E/B, PCG-NV77M/BP, PCG-NV7EL, PCG-NV7L, PCG-NV90, PCG-NV90E, PCG-NV95EN, PCG-NV99E/B, PCG-NV99M/BP, PCG-QR1/BP, PCG-QR1E/BP, PCG-QR1S/BP, PCG-QR3/BP, PCG-QR3E/BP, PCG-QR3S/BP, PCG-R505/ABD, PCG-R505/ABV, PCG-R505/ASP, PCG-R505/BW, PCG-R505/SP, PCG-R505AFH, PCG-R505AFT, PCG-R505AGT, PCG-R505CT, PCG-R505DT, PCG-R505F/BD, PCG-R505F/BP, PCG-R505FR, PCG-R505FR/D, PCG-R505GL, PCG-R505GLK, PCG-R505J/BD, PCG-R505MFL, PCG-R505MGH, PCG-R505MGL, PCG-R505MP, PCG-R505Q/B, PCG-R505Q/BD, PCG-R505R/AK, PCG-R505R/DK, PCG-R505R/GK, PCG-R505R/K, PCG-R505S/PD, PCG-R505S/PS, PCG-R505TFL, PCG-R505TFF, PCG-R505V/BD, PCG-R505VF/K, PCG-R505VJ/K, PCG-R505VM/K, PCG-R505VM/P, PCG-R505W/P, PCG-R505W/PD, PCG-R505X/P, PCG-R505X/PD, PCG-XE17, PCG-XR100F/K, PCG-XR1F/BP, PCG-XR1Z/BP, PCG-XR7F/K, PCG-XR7Z/BP, PCG-XR7Z/K, PCG-XR9F/K, PCG-XR9Z/K, PCG-Z505C/BP, PCG-Z505CR/K, PCG-Z505CR/P, PCG-Z505D, PCG-Z505DX, PCG-Z505F, PCG-Z505FX, PCG-Z505GAT, PCG-Z505GATH, PCG-Z505GATM, PCG-Z505J/BP, PCG-Z505JL, PCG-Z505JX, PCG-Z505V/BP, PCG-Z505VR/K, PG32, QR10, QR20, R500, R505B/P, R505CT, R505D, R505DS, R505DSK, R505DT, R505J, R505MP, R505MXX, R505T, R505TE, R505TEK, R505TFF, R505TS, R505TXCP, R505TZCP, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, VGN-A115B, VGN-A115S, VGN-A115Z, VGN-A117S, VGN-A130, VGN-A130B, VGN-A130B28, VGN-A130P, VGN-A140, VGN-A140B, VGN-A140P, VGN-A150, VGN-A15GP, VGN-A15LP, VGN-A160, VGN-A170, VGN-A170B, VGN-A170P, VGN-A17GP, VGN-A17LP, VGN-A17SP, VGN-A190, VGN-A195EP, VGN-A195HP, VGN-A197VP, VGN-A197XP, VGN-A19GP, VGN-A19LP, VGN-A19SP, VGN-A215M, VGN-A215Z, VGN-A217M, VGN-A217S, VGN-A21C, VGN-A230B1, VGN-A230P, VGN-A240, VGN-A250, VGN-A260, VGN-A270, VGN-A270B, VGN-A270P, VGN-A290, VGN-A295HP, VGN-A297XP, VGN-A29LP, VGN-A29SP, VGN-A317S, VGN-A39GP, VGN-A49GP, VGN-A50B, VGN-A51PS, VGN-A51S, VGN-A59GP, VGN-A60091, VGN-A60B, VGN-A60GP, VGN-A60PS, VGN-A60S, VGN-A61B, VGN-A62B, VGN-A63, VGN-A690, VGN-A70P, VGN-A70PS, VGN-A70S, VGN-A71PS, VGN-A71S, VGN-A72PB, VGN-A72PS, VGN-A72S, VGN-A73PS, VGN-A73S, VGN-A74PS, VGN-A74S, VGN-A790, VGN-AS33B, VGN-AS53B, VGN-AS53PS, VGN-AS53S, VGN-CR11S/L, VGN-CR11S/L, VGN-CR11S/W, VGN-CR120E/L, VGN-CR120E/P, VGN-CR120E/R, VGN-CR120E/W, VGN-CR123E/B, VGN-CR125E/B, VGN-CR131E/BC, VGN-CR131E/L, VGN-CR140E/B, VGN-CR140N/B, VGN-CR150E/B, VGN-CR190, VGN-CR190E/L, VGN-CR190E/P, VGN-CR190E/R, VGN-CR190E/W, VGN-CR190N2, VGN-CR19VN/B, VGN-CR19XN/B, VGN-CR21E/L, VGN-CR21E/P, VGN-CR21E/W, VGN-CR21S/P, VGN-CR21S/W, VGN-CR240N/B, VGN-CR290EAL, VGN-CR290EAN, VGN-CR290EAP, VGN-CR290EAR, VGN-CR290EAW, VGN-CR29XN/B, VGN-E50B/B, VGN-E50B/D, VGN-E50B/S, VGN-E51B/D, VGN-E51B/S, VGN-E70B/B, VGN-E70B/S, VGN-E71B/G, VGN-E71B/S, VGN-E72B/D, VGN-E72B/G, VGN-E72B/S, VGN-E81B/B, VGN-E91B/B, VGN-E92B/B, VGN-FE590GC, VGN-FE590P03, VGN-FE690GB, VGN-FR820, VGN-FR825P, VGN-FS115B, VGN-FS115E, VGN-FS115M, VGN-FS115S, VGN-FS115Z, VGN-FS195VP, VGN-FS195XP, VGN-FS500, VGN-FS500P, VGN-FS500P12, VGN-FS520B, VGN-FS530B, VGN-FS540P, VGN-FS550, VGN-FS550P, VGN-FS570, VGN-FS620P/W, VGN-FS625B/W, VGN-FS630/W, VGN-FS635B/W, VGN-FS640/W, VGN-FS645P/H, VGN-FS660/W, VGN-FS660P/W, VGN-FS675P/H, VGN-FS680/W, VGN-FS690, VGN-FS690B, VGN-FS690P, VGN-FS710/W, VGN-FS715/W, VGN-FS720/W, VGN-FS730/W, VGN-FS740/W, VGN-FS742/W, VGN-FS750P/W, VGN-FS770/W, VGN-FS830/W, VGN-FS840/W, VGN-FS850, VGN-FS850/W, VGN-FS850P, VGN-FS850P/W, VGN-FS875P/H, VGN-FS8900P3, VGN-FS8900P4, VGN-FS8900P5, VGN-FS920, VGN-FS940, VGN-FS960P, VGN-FS980, VGN-FS990, VGN-FZ140E/B, VGN-FZ140N/B, VGN-FZ145E/B, VGN-FZ150E/BC, VGN-FZ190 (Intel Graphic Card), VGN-FZ250E/B, VGN-N320E, VGN-NR160E/S, VGN-NR160E/T, VGN-NR160E/W, VGN-NR180E/S, VGN-NR180E/T, VGN-SZ650N/C (Intel Graphic card), VGN-SZ670N/C (Intel Graphic card), VGN-SZ691N/X (Intel Graphic card), X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG29K, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK

Notebook Tip 12

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Sotec	3120X, 3123XS	Notebook Tip 03
Tandy	3830SL, 3830SL/C	Notebook Tip 06
	1500HD, 1800HD, 2810HD, 2820HD, 3800HD, 3810HD, 3820HD	Notebook Tip 11
Texas Instruments	Extensa Range – 350, 365, 390, 550, 550CD, 550CDT, 560, 560CD, 560CDT, 565, 565CD, 565CDT, 570, 570CD, 570CDT, 900, 900CDT, 900T	Notebook Tip 03
Tiger Direct	DESIGNote 5200, DESIGNote 5200 GT, GT GT	Notebook Tip 03
Toshiba	Dynabook Satellite I400, Dynabook Satellite I410	Notebook Tip 03
	Equium Range – A100-549, A100-602, L10-142, L10-200, L100-186, L20-197, L20-198, L20-264, M40X-149, M50-159, M50-192, M50-216, M50-218, M50-244, M70-173, M70-337, M70-339, M70-364	
	Portege M400-100, Portege M400-103, Portege M400-105, Portege M400-109, Portege M400-100	
	Satellite Range – 1000-S157, 1000-S158, 1005-S157, 1005-S158, 1100, 1100-S101, 1100-Z6, 1105, 1200, 1200-S121, 1200-S122, 1605CDS, 1620CDS, 1625CDT, 1640CDT, 1670CDS, 1675CDS, 1690CDT, 1695CDT, 1700-200, 1700-300, 1710CDS, 1715XCDS, 1730, 1730CDT, 1735, 1750, 1755, 3000-100, 3000-400, 3000-514, 3000-S304, 3000-S353, 3000-X11, 3000-X4, 3005-S303, 3005-S304, 3005-S307, 3005-S403, 35DVD, A100-003, A100-011, A100-036, A100-151, A100-163, A100-165, A100-181, A100-188, A100-193, A100-209, A100-212, A100-218, A100-220, A100-232, A100-241, A100-250, A100-269, A100-270, A100-274, A100-287, A100-290, A100-294, A100-295, A100-303, A100-436, A100-437, A100-467, A100-500, A100-507, A100-508, A100-510, A100-513, A100-521, A100-522, A100-523, A100-524, A100-525, A100-533, A100-534, A100-535, A100-551, A100-561, A100-565, A100-570, A100-571, A100-590, A100-597, A100-649, A100-661, A100-662, A100-669, A100-712, A100-717, A100-766, A100-768, A100-784, A100-786, A100-787, A100-788, A100-811, A100-813, A100-847, A100-906, A100-912, A100-920, A100-S2211TD, A100-S2311TD, A100-S8111TD, A100-SP621, A100-ST1041, A100-ST3211, A100-VA1, A100-VA104C, A100-VA5, A100-WA1, A105-2715, A105-S101, A105-S1013, A105-S1014, A105-S171, A105-S1712, A105-S2011, A105-S2021, A105-S2031, A105-S2051, A105-S2061, A105-S2071, A105-S2081, A105-S2091, A105-S2141, A105-S2201, A105-S2231, A105-S2236, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S361, A105-S3611, A105-S4022, A105-S4102, A105-S4132, A110-101, A110-110, A110-133, A110-142, A110-162, A110-177, A110-178, A110-195, A110-203, A110-212, A110-225, A110-228, A110-253, A110-260, A110-274, A110-275, A110-277, A110-289, A110-293, A110-294, A110-334, A110-339, A110-381, A110-ST1111, A135-S2256, A135-S2266, A135-S2276, A135-S2286, A135-S2296, A135-S2306, A135-S4407, A135-S4417, A135-S4427, A135-S4437, A135-S4447, A135-S4457, A135-S4467, A135-S4477, A135-S4478, A135-S4487, A135-S4488, A135-S4517, A135-S4677, A135-S4747, A200-10Z, A200-11C, A200-130, A200-13R, A200-1CR, A200-1FJ, A200-1m7, A205-S4587, A205-S4617, A205-S4777, A205-S4797, A215-S4807, A60-127, A80-S178TD, L10-107, L10-114, L10-132, L10-151, L10-190, L10-282, L100-103, L100-104, L100-105, L100-111, L100-121, L100-140, L100-141, L100-165, L100-170, L100-171, L100-173, L100-175, L100-179, L100-194, L10Q, L15-S104, L20-101, L20-112, L20-118, L20-120, L20-121, L20-135, L20-149, L20-153, L20-155, L20-157, L20-159, L20-173, L20-181, L20-182, L20-183, L20-188, L20-196, L20-204, L20-205, L20-217, L20-256, L20-268, L20-S310TD, L20-SPI19, L20-SP231, L25-S119, L25-S1192, L25-S1193, L25-S1194, L25-S1195, L25-S1196, L25-S121, L25-S1216, L25-SPI39, L25-SPI41, L30-101, L30-105, L30-10S, L30-114, L30-115, L30-11D, L30-11E, L30-11G, L30-134, L30-142, L35-S1054, L35-S2151, L35-S2161, L35-S2171, L35-S2174, L35-S2194, L35-S2316, L35-S2366, L40-12X, L40-13G, L45-S2416, L45-S2687, L45-S4687, L45-S7409, L45-S7419, L45-S7423, L45-S7424, M100-152, M100-178, M100-179, M100-180, M100-195, M100-221, M100-222, M105-S1011, M105-S1021, M115-S1061, M115-S1064, M115-S1071, M30X, M30X-102, M30X-104, M30X-105, M30X-106, M30X-107, M30X-108, M30X-111, M30X-113, M30X-115, M30X-118, M30X-122, M30X-124, M30X-125, M30X-127, M30X-128, M30X-129, M30X-130, M30X-131, M30X-134, M30X-142, M30X-143, M30X-144, M30X-148, M30X-150, M30X-154, M30X-155, M30X-156, M30X-159, M30X-161, M30X-162, M30X-163, M30X-165, M30X-166, M30X-167, M30X-168, M30X-169, M30X-170, M30X-173, M30X-174, M30X-A1592ST, M30X-S1593ST, M30X-S171ST, M30X-S181ST, M30X-S191TD, M30X-S221TD, M35X-S109, M35X-S111, M35X-S114, M35X-S149, M35X-S1491, M35X-S1492, M35X-S161, M35X-S1611, M35X-S163, M35X-S1631, M35X-S309, M35X-S3091, M35X-S311, M35X-S3111, M35X-S3112, M35X-S329, M35X-S3291, M35X-S349, M35X-S3491, M35X-SPI81, M40X-112, M40X-115, M40X-116, M40X-119, M40X-129, M40X-154, M40X-159, M40X-161, M40X-163, M40X-166, M40X-175, M40X-183, M40X-184, M40X-231, M40X-250, M40X-251, M45-S165, M45-S1651, M45-S169, M45-S1691, M50-101, M50-102, M50-105, M50-106, M50-108, M50-109, M50-113, M50-115, M50-122, M50-124, M50-126, M50-137, M50-138, M50-141, M50-142, M50-143, M50-145, M50-148, M50-156, M50-163, M50-164, M50-168, M50-170, M50-176, M50-180, M50-181, M50-182, M50-183, M50-187, M50-196, M50-198, M50-203, M50-215, M50-226, M50-227, M50-228, M50-231, M50-247, M50-252, M55-S1001, M55-S139, M60-161, M65-S8092, M65-S8213, M70-122, M70-129, M70-131, M70-144, M70-151, M70-152, M70-159, M70-160, M70-168, M70-169, M70-175, M70-181, M70-186, M70-187, M70-189, M70-190, M70-191, M70-192, M70-193, M70-194, M70-196, M70-212, M70-217, M70-236, M70-238, M70-239, M70-252, M70-258, M70-267, M70-340, M70-343, M70-348, M70-354, M70-356, M70-376, M70-394, M70-395, M70-396, P100-223, P100-253, P100-284, P100-340, P200-140, P205-S6267, P205-S6307, P205-S6327, P205-S6337, P205-S6347, P205-S6347, R20-110, R20-112, U200-10H, U200-163, U200-165, U300-10M, U300-111, U300-ST3091, U300-ST3094, U305-S5077, U305-S5087, U305-S5097, U305-S5107, U305-S5127, U305-S57402, U305-S7432, U305-S7446, U305-S7448, U305-S7449, U305-S7467, U305-S7477	

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Toshiba	<p>Satellite Pro Range – A100, A100-01A, A100-03R, A100-229, A100-240, A100-242, A100-244, A100-247, A100-262, A100-263, A100-264, A100-296, A100-297, A100-415, A100-501, A100-511, A100-514, A100-518, A100-531, A100-532, A100-536, A100-538, A100-545, A100-564, A100-574, A100-577, A100-622, A100-707, A100-708, A100-722, A100-848, A100-908, A120-106, A120-10K, A120-10L, A120-169, A200-1M9, A200-1MH, A200-1Mi, L10, L10-103, L10-118, L10-175, L10-178, L10-184, L10-185, L100, L100-132, L100-176, L20, L20-102, L20-103, L20-137, L20-148, L20-184, L20-189, L20-211, L20-258, L20-259, L40-12Q, L40-12R, L40-12S, L40-12T, L40-135, M40, M40-274, M40-275, M40-280, M40-301, M40-325, M40X-132, M40X-134, M40X-165, M40X-167, M40X-168, M40X-169, M50-238, M50-239, M50-240, M50-241, M50-242, M70, M70-109, M70-110, M70-113, M70-125, M70-126, M70-132, M70-134, M70-137, M70-154, M70-178, M70-198, M70-199, M70-220, M70-235, M70-237, M70-275, M70-299, M70-307, M70-317, M70-325, M70-326, M70-327, M70-331, M70-332, M70-333, S200-112, U200-101, U200-129, U200-132, U200-155, U200-182, U300-116, U300-11K</p> <p>Tecra Range – A6-141, A7-110, A7-112, A7-114, A7-202, A7-209, A7-221, A7-232, A7-248, A8-10D, A8-10G, A8-10H, A8-117, A8-127, A8-129, A8-130, A8-132, A8-143, A8-150, A8-159, A8-185, A8-210, A9-51E, A9-51F, A9-51G, L2-S011, L2-S022, M5-103, M5-104, M5-118, M5-119, M5-133, M5-292, M5-383, M5-384, M5-415, M5-417, M7-117, M7-121, M7-132, M7-133, M7-141, M8-S8011, M8-ST3093, M8-ST3094, M9-12K</p> <p>Dynabook M35 166D/2W</p>	Notebook Tip 03
	<p>Dynabook Satellite Range – 1800, 1830, 1850, 1860, 1870, 2140, 2400, 2410, 2800, 5000, 5100, A10, A11 220P/4, A11 220P/5, A11 240C/4, A11 240C/5, A50 01900M, A50 01900N, A50 01F00M, A50 01F00N, A50 02700M, A50 03900N, A50 08K00N, A50 08L00N, J11 220P/4, J11 220P/5, J11 220P/5X, J11 240C/4, J11 240C/5X, J12 250C/4, J12 250C/5, J12 250C/5X, J30 140L/4, J30 140L/5, J30 140L/5X, J30 180L/5X, J31 150L/4, J31 150L/5, J32 130C/4, J32 130C/5, J32 130C/5X, J32 150L/5X, J32 160L/4, J32 160L/5, J32 160L/5X, M30, T10 130C/4, T10 130C/5, T10 150L/4, T10 150L/5, T11 130C/4, T11 130C/5, T11 160L/4, T11 160L/5</p>	Notebook Tip 06
	<p>Dynabook Satellite Pro 440, Dynabook Satellite Pro 460, Dynabook Satellite Pro 480, Dynabook Satellite Pro 490</p>	
	<p>Dynabook SS Range – 1600, 1610, 2000, 2010, 2100, 2110, 2120, 3500, 4000, M10, M3, MX, S, S4, S5, S6, S7, S8, S9, SX</p>	
	<p>Equium L10-206, Equium L10-273, Equium L10-300, Libretto 60, Libretto L, Libretto U100, Libretto U100-S213, Libretto U105</p>	
	<p>Portege Range – 2000, 2010, 3500 Tablet, 3505 Tablet, 4000, 4005, 4010, 7000CT, 7010CT, 7020CT, 7140CT, 7200CT/Cte, 7220Cte, A100, A200, A200-120, M100, M100-101, M100-104, M100-105, M100-106, M100-107, M100-112, M100-122, M200, M200 P-M 750, M200-100, M200-101, M200-102, M200-105, M200-122, M200-142, M200-152, M200-160, M200-171, M200-172, M200-173, M200-S218TD, M200-S838, M205, M205-S809, M205-S810, M300, M300-100, M300-101, M300-102, M300-103, M300-104, M300-105, M400-139, M400-EZ5031, M400-S4032, M400-S5032, M400-S5032X, M400-S933, M400-ST4001, M400-ST4035, M405-S8003, R100, R100-102, R100-103, R150, R200, R200-110, R200-S2031, R200-S2062, R200-S234, R205-S2062, R205-S209, R400-S4831, R400-S4832, R400-S4833, R400-S4834, R400-S4835, R400-S4931, R400-S4933, R500-S5001X, R500-S5002, R500-S5002X, R500-S5003, R500-S5004, RS100, S100-S1133, S100-S113TD, S100-S213TD</p>	
	<p>Qosmio E10, Qosmio E10-102</p>	
	<p>Satellite Range – 1600, 1610, 2000, 2010, 2100, 2110, 2120, 3500, 4000, M10, M3, MX, S, S4, S5, S6, S7, S8, S9, SX</p>	

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Toshiba	<p>Satellite Range – 1400, 1400-103, 1400-153, 1400-203, 1400-253S, 1400-553S, 1400-S151, 1400-S152, 1405, 1405-S151, 1405-S152, 1405-S171, 1405-S172, 1410, 1410-303, 1410-303x, 1410-304, 1410-354, 1410-401, 1410-554, 1410-604, 1410-704, 1410-714, 1410-801, 1410-802, 1410-814, 1410-902, 1410-S102, 1410-S103, 1410-S105, 1410-S106, 1410-S173, 1410-S174, 1410-S203, 1415, 1415-S105, 1415-S106, 1415-S115, 1415-S173, 1415-S174, 1550CDS, 1555, 1555CDS, 1800, 1800-100, 1800-254S, 1800-314, 1800-354S, 1800-364E, 1800-400, 1800-412, 1800-452E, 1800-514, 1800-554S, 1800-614, 1800-654S, 1800-700, 1800-712, 1800-752S, 1800-921, 1800-S203, 1800-S204, 1800-S206, 1800-S207, 1800-S253, 1800-S254, 1800-S256, 1800-S274, 1805, 1805-S154, 1805-S177, 1805-S203, 1805-S204, 1805-S207, 1805-S208, 1805-S253, 1805-S254, 1805-S255, 1805-S273, 1805-S274, 1805-S278, 200, 2060, 2065, 2100, 2105, 2140, 2140XCDS, 2180CDT, 220, 220CT, 2210, 2210CDT/XCDS, 2230, 2250, 2250XCDS, 225CDS, 2400, 2405, 2410, 2410-303, 2410-304, 2410-304S, 2410-404, 2410-413, 2410-414, 2410-514, 2410-515, 2410-601, 2410-603, 2410-702, 2410-703, 2410-S203, 2410-S205, 2410-S403, 2410-S453, 2415, 2415-S205, 2430, 2500CDS, 2500CDT, 2505CDS, 2505CDT, 2510, 2515CDS, 2520, 2530, 2535CDS, 2540, 2545, 2550, 2590CDS, 2590CDT/CDS/CDT/XDVD, 2595CDS, 2595CDT, 2595XDVD, 2610, 2615DVD, 2650, 2655XDVD, 2670, 2675DVD, 2695, 2710, 2715XDVD, 2740, 2750, 2755DVD, 2770, 2775XDVD, 2800, 2800-S201, 2800-S202, 2805, 2805-S201, 2805-S202, 2805-S203, 2805-S302, 2805-S401, 2805-S402, 2805-S503, 2805-S603, 300, 310, 320, 330, 4000CDS, 4000CDS/CDT, 4005CDS, 4005CDS/CDT, 4010CDS, 4010CDS/CDT, 4015CDS/CDT, 4020CDT, 4025CDT, 4030CDT, 4060, 4070, 4080CDT, 4085, 4090XDVD, 4090ZDVD, 4100, 4100XDVD, 5005, 5005-S504, 5005-S507, 5005-S508, 5100-201, 5100-501, 5100-503, 5100-603, 5105, 5105-S501, 5105-S502, 5105-S607, 5105-S608, 5105-S701, 5105-S702, 5105-S901, 5200, 5200-701, 5200-702, 5200-711, 5200-801, 5200-802, 5200-901, 5200-902, 5200-903, 5200-904, 5200-S702, 5205, 5205-S119, 5205-S503, 5205-S504, 5205-S505, 5205-S506, 5205-S703, 5205-S704, 5205-S705, 5205-SP505, 5220, A10, A10-131, A10-501, A10-511, A10-521, A10-S100, A10-S1001, A10-S103, A10-S113, A10-S127, A10-S128, A10-S129, A10-S1291, A10-S167, A10-S169, A10-S1691, A10-S177, A10-S178, A10-S203, A10-S213, A10-S223, A10-S403D, A10-S503, A10-S513, A10-S603, A10-S613, A10-S703, A10-S811, A100-528, A100-529, A105-S2001, A105-S4011, A105-S4024, A105-S4034, A105-S4054, A105-S4064, A105-S4074, A105-S4084, A105-S4094, A105-S4114, A105-S4134, A105-S4164, A105-S4201, A15, A15-S127, A15-S128, A15-S129, A15-S1291, A15-S1292, A15-S157, A15-S158, A15-S169, A50, A50-100, A50-101, A50-102, A50-104, A50-105, A50-106, A50-108, A50-109, A50-110, A50-111, A50-112, A50-114, A50-120, A50-122, A50-402, A50-412, A50-432, A50-452, A50-492, A50-502, A50-512, A50-522, A50-523, A50-532, A50-542, A50-543, A50-S135, A50-S310B, A50-S310G, A50-S311G, A50-S330B, A50-S330G, A50-S332B, A50-S332G, A50-S333B, A50-S336G, A50-S430B, A50-S430G, A50-S432B, A50-S432G, A50-S535B, A50-S535G, A50-S536B, A50-S536G, A50-S537B, A50-S537G, A55, A55-S106, A55-S1063, A55-S1066, A55-S129, A55-S1291, A55-S179, A55-S1791, A55-S306, A55-S3061, A55-S3062, A55-S3063, A55-S326, A55-S3261, L10-100, L10-101, L10-102, L10-103, L10-104, L10-105, L10-108, L10-113, L10-117, L10-119, L10-120, L10-121, L10-123, L10-125, L10-130, L10-137, L10-144, L10-146, L10-154, L10-161, L10-167, L10-192, L10-193, L10-194, L10-202, L10-204, L10-205, L10-209, L10-223, L10-224, L10-226, L10-232, L10-269, L10-270, L10-272, L10-281, L10-333, L15-190, M20, M20-S257, M20-S257 Small Business, M20-S258, M30, M30 Special, M30-100, M30-103, M30-104, M30-105, M30-106, M30-107, M30-114, M30-125, M30-154, M30-164, M30-204, M30-241, M30-261, M30-304, M30-344, M30-354, M30-361, M30-404, M30-604, M30-622, M30-642, M30-704, M30-714, M30-742, M30-801, M30-832, M30-841, M30-842, M30-852, M30-853, M30-861, M30-901, M30-941, M30-951, M30-993, M30-PM725B, M30-PM725G, M30-PM760B, M30-S309, M30-S3091, M30-S350, M30-S3501, M30-S730, M30-S7301, M30-S7301B, M30-S7302, M30-S7302B, M30-S731, M30-S734B, M30-S734G, M30-S760, M35, M35-S320, M35-S3201, M35-S359, M35-S3591, M35-S3592, M35-S456, M35-S4561, M40-100, M40-101, M40-102, M40-103, M40-107, M40-110, M40-114, M40-124, M40-129, M40-130, M40-133, M40-134, M40-135, M40-136, M40-140, M40-142, M40-145, M40-146, M40-148, M40-149, M40-150, M40-152, M40-154, M40-155, M40-183, M40-184, M40-185, M40-192, M40-193, M40-197, M40-221, M40-225, M40-230, M40-231, M40-232, M40-236, M40-237, M40-238, M40-239, M40-241, M40-243, M40-244, M40-245, M40-250, M40-276, M40-277, M40-284, M40-288, M40-289, M40-294, M40-295, M40-296, M40-300, M40-307, M40-313, M40-319, M40-S4111TD, M40-S4172TD, M40-S4177TD, M45-S265, M45-S2651, M45-S2652, M45-S2653, M45-S269, M45-S2691, M45-S2692, M45-S331, M45-S3311, M45-S351, M45-S3511, M45-S355, M45-S3551, M45-S3552, M45-S3553, M45-S359, M45-S3591, M45-SP459, M45-SP469, M5-ST8112, M50-04N01N, M50-0TG01D, M50-0TJ01E, M50-0YU01N, M50-130, M50-157, M50-159, M50-161, M50-S4182TD, M50-S4187TD, M50-S5181TD, M50-S5181TQ, M55-S135, M55-S1351, M55-S1352, M55-S2252, M55-S2253, M55-S325, M55-S3251, M55-S329, M55-S3291, M55-S3292, M55-S3293, M55-S3294, M55-S331, M55-S3311, M55-S3314, M55-S3315, M55-S351, M55-S3511, M55-S3512, M55-SP329, M55-SP339, M55-SP341, M55-SP361, P100-160, R10-101, R10-S802TD, R10-S804TD, R10-S820, R15-S822, R15-S829, R20-ST4113, R25-S3503, R25-S3513, U200-148, U200-ST2092, U200-ST3311, U205, U205-S5002, U205-S5021, U205-S5022, U205-S5034, U205-S5044, U205-S5057, U205-S5058, U205-S5067, U205-S5068</p>	Notebook Tip 06
	<p>Satellite Pro Range – 2100, 2100-200Eb, 2100-200Ec, 2100-201Ec, 2100-203Eb, 2100-203Ec, 2100-220Eb, 2100-220Ec, 2100-221Eb, 2100-221Ec, 2100-401Eb, 2100-402Eb, 2100-403Eb, 2100-403Ec, 2100-404Eb, 2100-404Ec, 2100-405Eb, 2100-405EG, 2100-405EU, 2100-406Eb, 4200, 4220, 4260DVD, 4280XDVD, 4280ZDVD, 430, 4300, 440CDT/CDX/CS, 445CDT/CDX, 4600, 460CDT/CDX, 465CDT/CDX, 470CDT, 480CDT, 490CDT/XCDT, 520CDT, 550CDT, 6000, 6050, 6070, 6100, A10, L10-110, L10-113, L10-222, L10-271, M10, M10-S405, M10-S406, M15, M15-S405, M15-S406, M30, M50, P100-423</p>	
	<p>Tecra Range –</p>	

Manufacturer	Model	iGo Connectors
Laptops / Notebooks		
Toshiba	Tecra Range – 520CDT, 550CDT, 780CDM, 780DVD, 8000, 8100, 8200, 9000, 9100, A1, A2, A2-102, A2-104, A2-105, A2-108, A2-113, A2-502, A2-512, A2-542, A2-552, A2-562, A2-572, A2-582, A2-703, A2-S119, A2-S139, A2-S20ST, A2-S219, A2-S239, A2-S316, A2-S336, A2-S4372ST, A3, A3-S611, A3-S631, A3-S711, A3-S731, A4, A4-108, A4-109, A4-111, A4-123, A4-127, A4-128, A4-131, A4-132, A4-157, A4-158, A4-160, A4-161, A4-163, A4-164, A4-165, A4-166, A4-168, A4-170, A4-171, A4-177, A4-179, A4-181, A4-187, A4-196, A4-201, A4-203, A4-204, A4-205, A4-207, A4-210, A4-211, A4-212, A4-213, A4-221, A4-223, A4-227, A4-230, A4-232, A4-234, A4-244, A4-246, A4-249, A4-253, A4-255, A4-256, A4-257, A4-S111TD, A4-S211, A4-S216, A4-S231, A4-S236, A4-S312TD, A4-S313, A4-SP619, A5, A5-101, A5-102, A5-104, A5-105, A5-109, A5-119, A5-120, A5-122, A5-132, A5-133, A5-134, A5-135, A5-138, A5-145, A5-148, A5-155, A5-159, A5-S116, A5-S237, A5-S416, A5-S516, A5-S6215TD, A5-SP519, A5-SP559, A8-0SG063, A8-0SH063, A8-0SJ063, A8-EZ8311, A8-EZ8312, A8-EZ8412, A8-EZ8413, A8-EZ8511, A8-EZ8511X, A8-EZ8512, A8-EZ8512X, A8-S8414, A8-S8513, A8-S8514, A9-S9013, A9-S9013X, A9-ST9001, M1, M2, M2-102, M2-107, M2-109, M2-171, M2-251, M2-302, M2-312, M2-402, M2-422, M2-D1500B, M2-D1600B, M2-D1600G, M2-D1800B, M2-D1800G, M2-P1700B, M2-P1700G, M2-S319, M2-S339, M2-S410, M2-S430, M2-S519, M2-S530, M2-S539, M2-S5392, M2-S630, M2-S730, M2-S7302ST, M2V, M2V-D1500G, M2V-P1600G, M2V-S310, M2V-S330, M2V-S3302ST, M3, M3 P-M 730, M3 P-M 740, M3 P-M 750, M3 P-M 760, M3-100, M3-101, M3-105, M3-112, M3-116, M3-117, M3-118, M3-122, M3-124, M3-127, M3-129, M3-131, M3-133, M3-134, M3-137, M3-138, M3-142, M3-156, M3-166, M3-177, M3-183, M3-184, M3-185, M3-192, M3-221, M3-222, M3-226, M3-258, M3-264, M3-265, M3-272, M3-279, M3-281, M3-307, M3-326, M3-S212TD, M3-S311, M3-S316, M3-S331, M3-S336, M3-SP719, M4, M4-100, M4-101, M4-102, M4-103, M4-105, M4-107, M4-114, M4-133, M4-138, M4-146, M4-150, M4-151, M4-154, M4-158, M4-163, M4-S115TD, M4-S315, M4-S335, M4-S415, M4-S435, M4-S515, M4-S535, M4-SP625, M5-S4331, M5-S5332, M6-EZ6611, M6-EZ6612, M6-ST3412, M7-S7331, M9-S5512X, M9-S5513X, M9-ST5511X (Intel Graphic card), S1, S1-105, S1-115, S1-116, S1-118, S1-123, S1-141, S1-151, S1-202, S1-252, S1-272, S1-342, S1-362, S1-372, S1-382, S2, S2-S511TD, S3-S411TD, TE2000, TE2100, TE2300	Notebook Tip 06
Trogon	E.3, T.22, TG-795, Green 759, Green 795	Notebook Tip 03
Twinhead	P88, P88TE, SlimNote 910CV, SlimNote 9133TV, SlimNote 9133TZ, SlimNote 9150TZ, SlimNote 9166TZ, SlimNote VX, SlimNote VXE, SlimNote VXE3	Notebook Tip 03
Winbook	J1, N, Si, Si2, X1, X2, X4, XL, XLi, XP, Z	Notebook Tip 03
Windrover	7400	Notebook Tip 02
	N30W	Notebook Tip 03